

# ***MA20 Series***

## ***User's Manual***

***No. G03-MA20-F***

***Rev: 6.0***

***Release date: August 26, 2024***

**Trademark:**

\* Specifications and Information contained in this documentation are furnished for information use only, and are subject to change at any time without notice, and should not be construed as a commitment by manufacturer.

---

---

# TABLE OF CONTENT

---

---

ENVIRONMENTAL SAFETY INSTRUCTION .....	iii
ENVIRONMENTAL PROTECTION ANNOUNCEMENT .....	iii
USER'S NOTICE .....	iv
MANUAL REVISION INFORMATION .....	iv
ITEM CHECKLIST .....	iv
CHAPTER 1 INTRODUCTION OF THE MOTHERBOARD	
1-1 SPECIFICATION .....	1
1-2 LAYOUT DIAGRAM .....	2
CHAPTER 2 HARDWARE INSTALLATION	
2-1 JUMPER SETTING .....	6
2-2 CONNECTORS AND HEADERS .....	10
2-2-1 REAR I/O BACK PANEL CONNECTORS .....	10
2-2-2 MOTHERBOARD INTERNAL CONNECTORS .....	12
2-2-3 HEADER PIN DEFINITION .....	15
2-3 MAXIMUM VOLTAGE & CURRENT LIMIT .....	19
CHAPTER 3 INTRODUCING BIOS	
3-1 ENTERING SETUP .....	20
3-2 BIOS MENU SCREEN .....	21
3-3 FUNCTION KEYS .....	21
3-4 GETTING HELP .....	21
3-5 MENU BARS .....	22
3-6 MAIN MENU .....	22
3-7 ADVANCED MENU .....	23
3-8 CHIPSET MENU .....	32
3-9 SECURITY MENU .....	34
3-10 BOOT MENU .....	36
3-11 SAVE & EXIT MENU .....	36
3-12 MEBX .....	37




## Environmental Safety Instruction

---

- Avoid the dusty, humidity and temperature extremes. Do not place the product in any area where it may become wet.
- 0 to 40 centigrade is the suitable temperature. (The figure comes from the request of the main chipset)
- Generally speaking, dramatic changes in temperature may lead to contact malfunction and crackles due to constant thermal expansion and contraction from the welding spots' that connect components and PCB. Computer should go through an adaptive phase before it boots when it is moved from a cold environment to a warmer one to avoid condensation phenomenon. These water drops attached on PCB or the surface of the components can bring about phenomena as minor as computer instability resulted from corrosion and oxidation from components and PCB or as major as short circuit that can burn the components. Suggest starting the computer until the temperature goes up.
- The increasing temperature of the capacitor may decrease the life of computer. Using the close case may decrease the life of other device because the higher temperature in the inner of the case.
- Attention to the heat sink when you over-clocking. The higher temperature may decrease the life of the device and burned the capacitor.

## Environmental Protection Announcement

Do not dispose this electronic device into the trash while discarding. To minimize pollution and ensure environment protection of mother earth, please recycle.



---

---

## USER'S NOTICE

COPYRIGHT OF THIS MANUAL BELONGS TO THE MANUFACTURER. NO PART OF THIS MANUAL, INCLUDING THE PRODUCTS AND SOFTWARE DESCRIBED IN IT MAY BE REPRODUCED, TRANSMITTED OR TRANSLATED INTO ANY LANGUAGE IN ANY FORM OR BY ANY MEANS WITHOUT WRITTEN PERMISSION OF THE MANUFACTURER.

THIS MANUAL CONTAINS ALL INFORMATION REQUIRED TO USE THIS MOTHER-BOARD SERIES AND WE DO ASSURE THIS MANUAL MEETS USER'S REQUIREMENT BUT WILL CHANGE, CORRECT ANY TIME WITHOUT NOTICE. MANUFACTURER PROVIDES THIS MANUAL "AS IS" WITHOUT WARRANTY OF ANY KIND, AND WILL NOT BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES (INCLUDING DAMAGES FOR LOSS OF PROFIT, LOSS OF BUSINESS, LOSS OF USE OF DATA, INTERRUPTION OF BUSINESS AND THE LIKE).

PRODUCTS AND CORPORATE NAMES APPEARING IN THIS MANUAL MAY OR MAY NOT BE REGISTERED TRADEMARKS OR COPYRIGHTS OF THEIR RESPECTIVE COMPANIES, AND THEY ARE USED ONLY FOR IDENTIFICATION OR EXPLANATION AND TO THE OWNER'S BENEFIT, WITHOUT INTENT TO INFRINGE.

## Manual Revision Information

Reversion	Revision History	Date
6.0	Sixth Edition	August 26, 2024

## Item Checklist

- ☒ Motherboard
- ☒ Cable(s)
- ☒ I/O Back panel shield

# Chapter 1

## Introduction of the Motherboard


### 1-1 Specification

Spec	Description
<b>Design</b>	<ul style="list-style-type: none"> <li>ATX form factor; PCB size: 30.5 x24.4 cm</li> </ul>
<b>Chipset</b>	<ul style="list-style-type: none"> <li><b>Intel Q670E Chipset:</b> MA20-Q6700 MA20-Q6702 (onboard TPM2.0) MA20-Q6700-A1 (Intel® i226) MA20-Q6702-A1 (Intel® i226, TPM2.0)</li> <li><b>Intel R680E Chipset:</b> MA20-R6800 MA20-R6802 (onboard TPM2.0) MA20-R6800-A1 (Intel® i226) MA20-R6802-A1 (Intel® i226, TPM2.0)</li> </ul>
<b>CPU Socket</b>	<ul style="list-style-type: none"> <li>Intel LGA 1700 Socket supports 12<sup>th</sup> /13<sup>th</sup>/14<sup>th</sup> Gen. Core processors (<b>Max.125W TDPs under 240A</b>)</li> </ul> <p><i>*Note: for detailed CPU support information please visit our website</i></p>
<b>Memory Slots</b>	<ul style="list-style-type: none"> <li>4* Long UDIMM DDR5 slot for 4* DDR5 4800/4000MHz DRAM Module</li> <li>Support dual channel function <i>Maximum capacity: up to 192GB</i></li> </ul> <p><i>*Note: MA20-R6800/R6802 series support ECC</i></p>
<b>Expansion Slots</b>	<ul style="list-style-type: none"> <li>2* PCI-Express Gen.4 x16 (*<b>PCIE1 &amp; PCIE4; total support 1* PCIe Gen.4 x16 or 2* PCIe Gen.4 x8</b>)</li> </ul> <p><i>*Note: PCIE1 slot share x16 lane band width with PCIE4 slot; Signal detect automatically.</i></p> <ul style="list-style-type: none"> <li>2*PCI-Express Gen.3 x1 slot (<b>PCIE2 &amp; PCIE3</b>)</li> <li>2*PCI-Express Gen.4x4 slot (<b>PCIE5 &amp; PCIE6</b>)</li> <li>1*PCI Slot</li> <li>1*M.2 E-key slot, type-2230 PCIe Gen.3 x1/USB2.0 interface supports CNVi (<b>M2E1</b>)</li> <li>1*M.2 B-Key slot,type-3042/3052,PCIe Gen.3 x1/USB3.2 Gen.2/USB2.0 interface) supports 4G/5G Module (<b>M2B1</b>)</li> <li>1*Nano-SIM card slot (<b>SIMCARD</b>)</li> </ul>
<b>Storage</b>	<ul style="list-style-type: none"> <li>4*SATAIII 6Gb/s port support RAID 0/1/5/10 (<b>SATA1_2/ SATA3_4</b>)</li> <li>1* M.2 M-key slot, type-2242/2280 PCIe x4 interface supports NVMe (<b>M2M1</b>)</li> <li>1* M.2 M-Key (type-2242/2280, PCIe Gen.4 x4/SATA interface) support NVMe(<b>M2M2</b>)</li> </ul>
<b>LAN Chips</b>	<ul style="list-style-type: none"> <li><b>MA20-Q6700 / MA20-Q6702 / MA20-R6800 / MA20-R6802:</b> 1* Intel i225-LM 2.5GbE (*for UL1 LAN port; <b>supports iAMT</b>) 2* Intel i225-V 2.5GbE (for UL2/UL3 LAN port)</li> <li><b>MA20-Q6700-A1 / MA20-Q6702-A1 / MA20-R6800-A1 / MA20-R6802-A1:</b></li> </ul>


	1* Intel i226-LM 2.5GbE ( <b>*for UL1 LAN port; supports iAMT</b> ) 2* Intel i226-V 2.5GbE ( <b>for UL2/UL3 LAN port</b> ) <i><b>*Note: 2500Mbps</b> high-speed transmission rate is <b>only</b> supported over CAT 5e UTP cable.</i>
<b>Audio Chip</b>	<ul style="list-style-type: none"> <li>Realtek HD Audio Codec integrated with Audio driver and utility included</li> </ul>
<b>BIOS</b>	<ul style="list-style-type: none"> <li>AMI 256M Bit Flash ROM</li> </ul>
<b>Multi I/O</b>	<p><b>Rear Panel I/O:</b></p> <ul style="list-style-type: none"> <li>2* RS232/422/485 COM port</li> <li>1* VGA port &amp; 1* Displayport &amp; 1* HDMI port (<b>*Support Triple Displays</b>)</li> <li>3* 2.5GbE RJ-45 LAN port (<b>*UL1 LAN supports Intel iAMT</b>)</li> <li>6* USB 3.2 (Gen.2) port</li> <li>1* 3-phone audio Jack(Line-in, Line-out, MIC)</li> </ul> <p><b>Internal I/O Connectors &amp; Headers:</b></p> <ul style="list-style-type: none"> <li>1* 24-pin main power connector</li> <li>1* 8-pin 12V power connector</li> <li>1* CPUFAN connector &amp; 2* SYSFAN connector</li> <li>1* Internal type-A USB 3.2 (Gen.2) port connector (<b>USB3</b>)</li> <li>1* Internal type-A USB 2.0 port connector (<b>REFLASH_USB</b>)</li> <li>1* Front panel header</li> <li>1* Front panel audio header</li> <li>1* HDMI_SPDIF header</li> <li>4* RS232 COM port header (<b>COM3/4/5/6</b>)</li> <li>1* 9-Pin USB 2.0 header for 2* USB 2.0 expansion ports</li> <li>1*19-Pin USB 3.2 (Gen.1) header for 2* USB 3.2 (Gen.1) ports</li> <li>1* 8-bit GPIO header</li> <li>1* PS/2 Keyboard &amp; Mouse header</li> <li>1* SMBUS header</li> </ul>
<b>TPM 2.0 Function</b>	<ul style="list-style-type: none"> <li>Optional for <b>MA20-R6702 &amp; MA20-R6802</b> Series</li> </ul>
<b>OS Support</b>	<ul style="list-style-type: none"> <li>for detailed OS support information please visit our website for latest update</li> </ul>

## 1-2 Layout Diagram

### Rear IO Diagram




# Motherboard Internal Diagram



**\*Note:** PCIE1: X16 or X8 (You can select x16 or x8, x8 from the BIOS); PCIE4: X8 (The BIOS must be x8 or x8). PCIE4 is functional.

**\*Note:** SIM card slot only functions **when** compatible Nano-SIM card installed in **SIMCARD** slot & compatible 3G/4G/5G card installed in **M2B1** slot.

## Motherboard Jumper Position:



## Jumper

Jumper	Name	Description	Pitch
JPCOM1	COM1 Port Pin9 Function Select	4-pin Block	2.54mm
JPCOM2	COM2 Port Pin9 Function Select	4-pin Block	2.54mm
JPCOM3	COM3 Header Pin9 Function Select	4-pin Block	2.54mm
JPCOM4	COM4 Header Pin9 Function Select	4-pin Block	2.54mm
JPCOM5	COM5 Header Pin9 Function Select	4-pin Block	2.54mm
JPCOM6	COM6 Header Pin9 Function Select	4-pin Block	2.54mm
JBAT1	Clear CMOS RAM Settings	3-pin Block	2.0mm
COPEN	Case Open Message Display Detect	2-pin Block	2.54mm
JAT_ATX	ATX/AT Mode Select	3-pin Block	2.54mm
JP1	ME Features Select	2-pin Block	2.54mm
JP2	GPIO1 Header Function Select	2-pin Block	2.54mm
*REFLASH_SW	For BIOS Reflash	2-pin Block	2.54mm



---

---

## Connectors

Connector	Name
COM1_2	RS232/422/485 Serial Port X2
VGA	VGA Port
HDMI	HDMI Port
DP	DisplayPort
UL1 (*LAN1 supports Intel iAMT)	<b>Top:</b> 2.5GbE RJ-45 LAN Port <b>Middle &amp; Bottom:</b> USB 3.2 (Gen.2) Port
UL2/UL3	<b>Top:</b> 2.5GbE RJ-45 LAN Port X2 <b>Middle &amp; Bottom:</b> USB 3.2 (Gen.2) Port X4
AUDIO	<b>Top:</b> Line-in Connector <b>Middle:</b> Line-out Connector <b>Bottom:</b> MIC Connector
ATXPWR1	ATX Type Main Power Connector
ATX12V1	ATX 12V Power Connector
SATA1_2/ SATA3_4	SATAIII Connector X4
CPUFAN1	CPU FAN Connector
SYSFAN1/2	System FAN Connector X2
USB3	<b>Internal</b> Type-A USB3.2 (Gen.2) Port Connector
*REFLASH_USB	<b>Internal</b> Type-A USB 2.0 Port Connector

\* **Note:** **REFLASH\_USB** functions as normal USB 2.0 port and is the designated USB port for re-flashing BIOS when BIOS update needed.

## Headers


Header	Name	Description	Pitch
FP (Front Panel Header)	PWR LED/ HD LED/ Power Button /Reset	9-pin Block	2.54mm
FP_AUDIO	Front Panel Audio Header	9-pin Block	2.54mm
HDMI_SPDIF	HDMI_SPDIF Header	2-pin Block	2.54mm
COM3/4/5/6	RS232 Serial Port Header X4	9-pin Block	2.54mm
FP_USB2	USB 2.0 Port Header	9-pin Block	2.54mm
FP_USB3	USB 3.2 (Gen.1) Port Header	19-pin Block	2.0mm
GPIO1	GPIO Header	10-pin Block	2.54mm
PS2KBMS	PS/2 Keyboards & Mouse Header	6-pin Block	2.54mm
SMBUS1	SMBUS Header	5-pin Block	2.54mm

# Chapter 2


## Hardware Installation

### 2-1 Jumper Setting


**JPCOM1 (4-pin): COM1 Port Pin9 Function Select**




**JPCOM1→COM1 Port Pin-9**



2-4 Closed:  
RI=RS232;




3-4 Closed:  
RI= 5V;




4-6 Closed:  
RI= 12V;


**JPCOM2 (4-pin): COM2 Port Pin9 Function Select**




**JPCOM2→COM2 Port Pin-9**



2-4 Closed:  
RI=RS232;




3-4 Closed:  
RI= 5V;



4-6 Closed:  
RI= 12V;

**JPCOM3/ JPCOM4/ JPCOM5 /JPCOM6 (4-pin): COM3/ COM4/ COM5/ COM6 Header Pin-9 Function Select**




**JPCOM3→COM3 Header Pin-9**


**JPCOM4→COM4 Header Pin-9**

**JPCOM5→COM5 Header Pin-9**


**JPCOM6→COM6 Header Pin-9**



2-4 Closed:  
PIN9=RS232;




3-4 Closed:  
PIN9=+5V;




4-6 Closed:  
PIN9=+12V


### ***JBAT1 (3-pin): Clear CMOS RAM Settings***



#### ***JBAT→Clear CMOS Settings***




**1-2 Closed: Normal;**




**2-3 Closed: Clear CMOS.**

### ***COPEN (2-pin): Case Open Message Display Function***




#### ***COPEN→ Case Open Detection***




**Pin 1-2 Short:** When Case open function pin short to GND, the Case open function was detected. When Used, needs to enter BIOS and enable 'Case Open Detect' function. In this case if your case is removed, next time when you restart your computer, a message will be displayed on screen to inform you of this.


### ***JAT\_ATX (3-pin): AT Mode /ATX Mode Select***



#### ***JAT\_ATX→ATX/AT Mode Select***




**1-2 Closed: ATX Mode Selected;**




**2-3 Closed: AT Mode Selected.**

**\*ATX Mode Selected:** Press power button to power on after power input ready;  
**AT Mode Selected:** Directly power on as power input ready.


**JP1(2-pin): ME Features Select**



**JP1 → ME Features Select**




1-2 Open: Enable ME Features(Default);




1-2 Closed: Disable ME Features.


**JP2(2-pin): GPIO1 Header Function Select**



**JP2 → GPIO1 Function Select**




1-2 Open: Function as Debug Port;




1-2 Closed: Function as GPIO Port.


**\*REFLASH\_SW(2-pin): For BIOS Reflash (via USB Disk)**




**REFLASH\_SW → for BIOS Update**



1-2 Open: Normal;



1-2 Short: about 0.5 Sec. for BIOS Update from REFLASH\_USB.



**\*Note:** Please refer to the following steps for BIOS update:

**Step-1:** Find a USB flash drive and format it into FAT32 format;


**Step-2:** Download the latest BIOS file and storage it into the USB flash drive (**FAT32 format**); Make sure that the file name of the BIOS file name changed into MB\_BIOS.BIN format.









**Step-3:** Plug the above-mentioned USB flash drive into the internal type-A USB port connector (**REFLASH\_USB**);

**Step-4:** Power on the system and then short Pin1&2 of **REFLASH\_SW** for about 0.5 sec.; the **REFLASH\_LED** will light up and then turn off, followed by flashing status indicating motherboard updating BIOS; the whole process will take about six and a half minutes. Make sure not to perform any other operations on motherboard during the process. When BIOS updating completed, the system will restart automatically, which means BIOS update is complete.


## 2-2 Connectors and Headers

### 2-2-1 Rear I/O Back Panel Connectors




Icon	Name	Function
	RS232/422/485 Serial Port	Mainly for user to connect external MODEM or other devices that supports Serial Communications Interface.
	VGA Port	To connect display device that support VGA specification.
	HDMI Port	To connect display device that support HDMI specification.
	Display Port	To the system to corresponding display device with compatible DP cable.
	2.5Gbps RJ-45 LAN Port (from UL1)	This connector is standard RJ-45 LAN jack for Network connection which supports 10/100/1000/2500 Mbps Ethernet data transfer rate. <b>LAN1 from UL1 supports Intel iAMT. (*Note: 2.5Gbps is only supported with CAT 5e UTP cable).</b>
	2.5Gbps RJ-45 LAN Port (from UL1 & UL3)	This connector is standard RJ-45 LAN jack for Network connection which supports 10/100/1000/2500 Mbps Ethernet data transfer rate. <b>(*Note: 2.5Gbps is only supported with CAT 5e UTP cable).</b>
	USB 3.2 (Gen.2) Port	To connect USB keyboard, mouse or other devices compatible with USB 3.2 (Gen.2) specification. Ports support up to 10Gbps data transfer rate.
	Audio Connectors	<b>BLUE:</b> Line-in Connector <b>GREEN:</b> Line-out Connector <b>PINK :</b> MIC Connector

## (1) RJ-45 Ethernet Connector



### UL1 (i225-LM / i226-LM) & UL2/UL3 (i225-V / i226-V) 2.5Gbps RJ-45 LAN port LED Signals:

\*\* There are two LED next to the LAN port. Please refer to the table below for the LAN port LED indications.



**A: Activity/Link LED**

Status	Description
Off	No Link
Blinking	Data Activity
On	Link


**B: Speed LED**

Status	Description
Off	10/100Mbps connection
Orange	1Gbps connection
Green	2.5Gbps connection

\* **Note:** 2.5Gbps high-speed transmission rate is **only** supported over **CAT 5e UTP cable**.

## (2) COM1\_2 (9-pin Block): RS232/422/485 Serial Port

The pin assignment for RS-232/ 422/ 485 is listed as follows:



**COM1 & COM2** port can function as RS232/422/485 port. In default settings COM1/2 functions as RS232 port. With compatible COM cable COM1 can function as RS422 or RS 485 port. User also needs to go to BIOS to set '**Transmission Mode Select**' for COM1/2 at first, before using specialized cable to connect different pins of this port.



---

---

## 2-2-2 Motherboard Internal Connectors

### (1) ATXPWR1 (24-pin block): Main Power Connector

ATX Power Supply connector: This is a new defined 24-pins connector that usually comes with ATX case. The ATX Power Supply allows using soft power on momentary switch that connect from the front panel switch to 2-pins Power On jumper pole on the motherboard. When the power switch on the back of the ATX power supply turned on, the full power will not come into the system board until the front panel switch is momentarily pressed. Press this switch again will turn off the power to the system board.

\*\* We recommend that you use an ATX 12V Specification 2.0-compliant power supply unit (PSU) with a minimum of 350W power rating. This type has 24-pin and 4-pin power plugs.

\*\* If you intend to use a PSU with 20-pin and 4-pin power plugs, make sure that the 20-pin power plug can provide at least 15A on +12V and the power supply unit has a minimum power rating of 350W. The system may become unstable or may not boot up if the power is inadequate.

\*\* If you are using a 20-pin power plug, please refer to Figure1 for power supply connection. Power plug form power supply and power connectors from motherboard both adopt key design to avoid mistake installation. You can insert the power plug into the connector with ease only in the right direction. If the direction is wrong it is hard to fit in and if you make the connection by force it is possible.





Figure1: 20-pin power plug








Figure 2: 24-pin power plug

### (2) ATX12V1 (8-pin block): 12V Power Connector

This is a new defined 8-pin connector that usually comes with ATX Power Supply that supports extra 12V voltage to maintain system power consumption. Without this connector might cause system unstable because the power supply can not provide sufficient current for system.







Pin	Definition	No.	Definition
1	GND	5	+12V
2	GND	6	+12V
3	GND	7	+12V
4	GND	8	+12V



### (3) CPUFAN1(4-pin): CPU Fan Connector

**CPUFAN1**



### (4) SYSFAN1 (3-pin): System Fan1 Connector


**SYSFAN1**



---


---

**(5) SYSFAN2 (3-pin): System Fan2 Connector**




**(6) SATA1\_2 & SATA3\_4(7-pin): SATAIII Port connector**

These are high-speed SATAIII ports that support 6GB/s transfer rate.



## (7) Dual Channel Memory Installation:




Configuration	DIMM1	DIMM2	DIMM3	DIMM4
1	install	--	install	--
2	--	install	--	install
3	install	install	install	install

### Notice!

- For dual channel installation, you need to install the same brand, speed, size and type memory module.
- It is unable to activate dual channel feature if you install one or three memory modules, or you install DIMM1 & DIMM4 / DIMM2 & DIMM3. Slot order can be from left-to-right or right-to-left, and it must be installed in pairs.
- If you install memory modules in wrong direction, it will damage the motherboard and memory module.

## 2-2-3 Header Pin Definition


### (1) FP (9-pin): Front Panel Header




---

## (2) FP\_AUDIO (9-pin): Line-Out, MIC-In Header


This header is connected to Front Panel Line-out, MIC connector with cable.



## (3) HDMI\_SPDIF (2-pin): HDMI-SPDIF Out header




## (4) COM3/4/5/6 (9-pin): RS232 Serial Port Header



---


---

(5) FP\_USB2 (9-pin): USB 2.0 Port Header




(6) FP\_USB3(19-pin):USB 3.2(Gen.1) Port Header

FP\_USB3 supports maximum 5Gbps data transfer rate due to hardware restrictions.



(7) GPIO1 (10-pin): 8-bit GPIO Port /Debug Port Header





**\*Note:** GPIO1 can function as Debug display port or GPIO port via JP2 jumper setting (refer to **Page-8** for JP2 description).



---

---

**(8) PS2KBMS (6-pin): PS/2 Keyboard & Mouse Header**



**(9) SMBUS1(5-Pin): SMBUS Header**



---

---

## 2-3 Maximum Voltage & Current Limit

Below is a list of maximum voltage & Current Limit specification for motherboard interface (including but not limited to slots, connectors and headers) for setup reference:

Parts		Working Voltage	Current Support
USB Ports from	<i>UL1</i>	5V	2A
	<i>UL2</i>	5V	2A
	<i>UL3</i>	5V	2A
	<i>USB3</i>	5V	2A
	<i>REFLASH_USB</i>	5V	2A
	<i>FP_USB2</i>	5V	2A
	<i>FP_USB3</i>	5V	2A
FP		5V	1A
<i>COM1_2/3/4/5/6</i>		5V/12V (via jumper setting)	0.5A
<i>GPIO1</i>		5V	1A
PS2KBMS		5V	0.5A
SMBUS1		3.3V	0.5A
SYSFAN1/2/CPUFAN1		12V	1.5A
M2M1		3.3V	2A
M2M2		3.3V	2A
M2E1		3.3V	2A
M2B1		3.3V	2A

---

---

## Chapter 3

# Introducing BIOS


**Notice!** The BIOS options in this manual are for reference only. Different configurations may lead to difference in BIOS screen and BIOS screens in manuals are usually the first BIOS version when the board is released and may be different from your purchased motherboard. Users are welcome to download the latest BIOS version from our official website.

The BIOS is a program located on a Flash Memory on the motherboard. This program is a bridge between motherboard and operating system. When you start the computer, the BIOS program will gain control. The BIOS first operates an auto-diagnostic test called POST (power on self test) for all the necessary hardware, it detects the entire hardware device and configures the parameters of the hardware synchronization. Only when these tasks are completed done it gives up control of the computer to operating system (OS). Since the BIOS is the only channel for hardware and software to communicate, it is the key factor for system stability, and in ensuring that your system performance as its best.

### 3-1 Entering Setup

Power on the computer and by pressing <Del> immediately allows you to enter Setup. If the message disappears before your respond and you still wish to enter Setup, restart the system to try again by turning it OFF then ON or pressing the “RESET” button on the system case. You may also restart by simultaneously pressing <Ctrl>, <Alt> and <Delete> keys. If you do not press the keys at the correct time and the system does not boot, an error message will be displayed and you will again be asked to

Press    **<Del>** to enter Setup






---

## 3-2 BIOS Menu Screen

The following diagram show a general BIOS menu screen:



## 3-3 Function Keys

In the above BIOS Setup main menu of, you can see several options. We will explain these options step by step in the following pages of this chapter, but let us first see a short description of the function keys you may use here:

- Press ←→ (left, right) to select screen;
- Press ↑↓ (up, down) to choose, in the main menu, the option you want to confirm or to modify.
- Press <Enter> to select.
- Press <+>/<-> keys when you want to modify the BIOS parameters for the active option.
- [F1]: General help.
- [F2]: Previous value.
- [F3]: Optimized defaults.
- [F4]: Save & Reset.
- Press <Esc> to quit the BIOS Setup.

## 3-4 Getting Help

### Main Menu

The on-line description of the highlighted setup function is displayed at the top right corner the screen.

### Status Page Setup Menu/Option Page Setup Menu

Press [F1] to pop up a small help window that describes the appropriate keys to use and the possible selections for the highlighted item. To exit the Help Window, press <Esc>.

---

---

## 3-5 Menu Bars


There are six menu bars on top of BIOS screen:

<b>Main</b>	To change system basic configuration
<b>Advanced</b>	To change system advanced configuration
<b>Chipset</b>	To change chipset configuration
<b>Security</b>	Password settings
<b>Boot</b>	To change boot settings
<b>Save &amp; Exit</b>	Save setting, loading and exit options.

User can press the right or left arrow key on the keyboard to switch from menu bar. The selected one is highlighted.

## 3-6 Main Menu

Main menu screen includes some basic system information. Highlight the item and then use the <+> or <-> and numerical keyboard keys to select the value you want in each item.



### System Date

Set the date. Please use [Tab] to switch between date elements.


### System Time

Set the time. Please use [Tab] to switch between time elements.

---

---

## 3-7 Advanced Menu



### ► **Connectivity Configuration**

Press [Enter] to make settings for the following sub-item:

#### **CNVi Mode**

This option configures connectivity.

[Auto Detection] means that if Discrete solution is discovered it will be enabled by default. Otherwise integrated solution (CNVi) will be enabled ;

[Disable Integrated] disables Integrated solution

The optional settings are: [Disable Integrated]; [Auto Detection]

### ► **CPU Configuration**

Press [Enter] to view current CPU configuration and make settings for the following sub-items:

#### **Hyper-Threading**

Use this item to enable or disable Hyper-Threading Technology

The optional settings: [Disabled]; [Enabled].

#### **Intel (VMX) Virtualization Technology**

When enabled, a VHM can utilize the additional hardware capabilities provided by Vanderpool Technology.

The optional settings: [Disabled]; [Enabled].

#### **Intel (R) SpeedStep™**

Use this item to allows more than two frequency ranges to be supported.

The optional settings: [Disabled]; [Enabled].

#### **C states**

Use this item to enable/disable CPU Power management. Allows CPU to go to C states when it's not 100% utilized.

The optional settings: [Disabled]; [Enabled].

#### **Turbo Mode**

Use this item to enable/disable processor turbo mode (requires EMTTM enabled too). AUTO means enabled.

The optional settings: [Disabled]; [Enabled].

### ► **SATA Configuration**

---

---

Press [Enter] to make settings for the following sub-items:

**SATA Controller(s)**

The optional settings are: [Enabled]; [Disabled].

When set as [Enabled], the following sub-items shall appear:

**M.2**

**Port**

Use this item to enable or disable SATA Port

The optional settings are: [Enabled]; [Disabled].

**SATA1/2/3/4**

**Port**

Use this item to enable or disable SATA Port

The optional settings are: [Enabled]; [Disabled].

**Hot Plug**

Use this item to designates this port as Hot Pluggable.

The optional settings are: [Enabled]; [Disabled].

► **PCH-FW Configuration**

Use this item to configure Management engine technology parameters

Press [Enter] to make settings for the following sub-items:

**TPM Device Selection**

Use this item to selects TPM device: PTT or dTPM. PTT- Enables PTT in SkuMgr  
dTPM 1.2 – Disables PTT in SkuMgr Warning! PTT/dTPM will be disabled and all  
data saved on it will be lost

The optional settings are: [dTPM]; [PTT].

► **Firmware Update Configuration**

Use this item to configure management engine technology parameters.

**Me FW Image Re-Flash**

Use this item to enable/disable Me FW Image Re-Flash function

The optional settings: [Disabled]; [Enabled]

► **Trusted Computing**

Press [Enter] to view ME information and make settings in the following  
sub-items:

**Security Device Support**

Use this item to enables or disables BIOS support for security device. O.S will not  
Show security device. TCG EFI protocol and INT1A interface will not be available.

The optional settings: [Disabled]; [Enabled].

When set as [Enabled], user can make settings in the following items that appear:

**Pending operation**

Use this item to schedule an operation for the security device. NOTE: Your  
computer will reboot during restart in order to change state of security device

**TPM Device Selection**

Use this item to selects TPM device: PTT or dTPM. PTT-Enables PTT in SkuMgr  
Dtpm 1.2 – Disables PTT in SkuMgr Warning! PTT/dTPM will be disabled and all  
data saved on it will be lost

The optional settings: [dTPM]; [PTT].

► **ACPI Settings**

---

---

Press [Enter] to make settings for the following sub-items:

**ACPI Settings**

**ACPI Sleep State**

Use this item to select the highest ACPI sleep state the system will enter when the suspend button is pressed.

The optional settings are: [Suspend Disabled]; [S3 (Suspend to RAM)].

► **Wake-up Function Settings**

**Wake-up System With Fixed Time**

Use this item to enable or disable system wake on alarm event. When enabled, system will wake on the hr: min: sec specified

The optional settings: [Disabled]; [Enabled].

When set as [Enabled], user can make settings in the following items that appear:

**Wake-up Hour**

Use this item to select 0-23 for example enter 3 for 3am and 15 for 3pm

**Wake-up Minute**

Use this item to select 0-59

**Wake-up Second**

Use this item to select 0-59

**Wake-up System with Dynamic Time**

*\*This item will only show when 'Wake-up System With Fixed Time' is set as [Disabled].*

Use this item to enable or disable system wake on alarm event. When enabled, system will wake on the current time + Increase minute(s)

When set as [Enabled], user can make settings in the following items that appear:

**Wake-up Minute Increase**

Use this item to select 1-60

**PS2 KB/MS Wake-up**

Use this item to enable or disable PS2 KB/MS Wake-up from (S3/S4/S5) Support only disable ERP function

The optional settings: [Disabled]; [Enabled].

**PCIe Wake-up from S3-S5**

The optional settings: [Disabled]; [Enabled].

**USB S3/S4 Wake-up**

Use this item to enable or disable USB S3/S4 Wake-up Support only disable ERP function

The optional settings: [Disabled]; [Enabled].

**USB S5 Power**

Use this item to USB Power after system shutdown support only isable ERP function

The optional settings: [Disabled]; [Enabled].

► **Super IO Configuration**

Press [Enter] to make settings for the following sub-items:

**Super IO Configuration**

**ERP Support**

Use this item to energy-related products function. Disable ERP to active all wake-up function.

The optional settings: [Disabled]; [Auto].

---

---

---

▶ **Serial Port 1 Configuration**

Press [Enter] to make settings for the following items:

**Serial Port**

Use this item to enable or disable serial port (COM).

The optional settings: [Disabled]; [Enabled].

**Change Settings**

Use this item to select an optimal setting for super IO device.

The optional settings are: [IO=3F8h; IRQ=4]; [IO=3F8h; IRQ=3,4,5,7,10,11]; [IO=2F8h; IRQ=3,4,5,7,10,11]; [IO=3E8h; IRQ=3,4,5,7,10,11]; [IO=2E8h; IRQ=3,4,5,7,10,11];

**Transmission Mode Select**

The optional settings are: [RS422]; [RS232]; [[RS485].

**Mode Speed Select**

Use this item to RS232/RS422/RS485 Speed Select

The optional settings are: [RS232/RS422/RS485=250Kbps]; [RS232=1Mbps, RS422/RS485=10Mbps];

▶ **Serial Port 2 Configuration**

Press [Enter] to make settings for the following items:

**Serial Port**

Use this item to enable or disable serial port (COM).

The optional settings: [Disabled]; [Enabled].

**Change Settings**

Use this item to select an optimal setting for super IO device.

The optional settings are: [IO=2F8h; IRQ=3]; [IO=3F8h; IRQ=3,4,5,7,10,11]; [IO=2F8h; IRQ=3,4,5,7,10,11]; [IO=3E8h; IRQ=3,4,5,7,10,11]; [IO=2E8h; IRQ=3,4,5,7,10,11];

**Transmission Mode Select**

The optional settings are: [RS422]; [RS232]; [[RS485].

**Mode Speed Select**

Use this item to RS232/RS422/RS485 Speed Select

The optional settings are: [RS232/RS422/RS485=250Kbps]; [RS232=1Mbps, RS422/RS485=10Mbps];

▶ **Serial Port 3 Configuration**

Press [Enter] to make settings for the following items:

**Serial Port**

Use this item to enable or disable serial port (COM).

The optional settings: [Disabled]; [Enabled].

**Change Settings**

Use this item to select an optimal setting for super IO device.

The optional settings are: [IO=3E8h; IRQ=10]; [IO=3F8h; IRQ=3,4,5,7,10,11]; [IO=2F8h; IRQ=3,4,5,7,10,11]; [IO=3E8h; IRQ=3,4,5,7,10,11]; [IO=2E8h; IRQ=3,4,5,7,10,11]; [IO=3E0h; IRQ=3,4,5,7,10,11]; [IO=2E0h; IRQ=3,4,5,7,10,11];

▶ **Serial Port 4 Configuration**

Press [Enter] to make settings for the following items:

**Serial Port**

Use this item to enable or disable serial port (COM).

The optional settings: [Disabled]; [Enabled].

---

---

---

### **Change Settings**

Use this item to select an optimal setting for super IO device.

The optional settings are: [IO=2E8h; IRQ=10]; [IO=3F8h; IRQ=3,4,5,7,10,11]; [IO=2F8h; IRQ=3,4,5,7,10,11]; [IO=3E8h; IRQ=3,4,5,7,10,11]; [IO=2E8h; IRQ=3,4,5,7,10,11]; [IO=3E0h; IRQ=3,4,5,7,10,11]; [IO=2E0h; IRQ=3,4,5,7,10,11];

#### ► **Serial Port 5 Configuration**

Press [Enter] to make settings for the following items:

##### **Serial Port**

Use this item to enable or disable serial port (COM).

The optional settings: [Disabled]; [Enabled].

##### **Change Settings**

Use this item to select an optimal setting for super IO device.

The optional settings are: [IO=3E0h; IRQ=11]; [IO=3F8h; IRQ=3,4,5,7,10,11]; [IO=2F8h; IRQ=3,4,5,7,10,11]; [IO=3E8h; IRQ=3,4,5,7,10,11]; [IO=2E8h; IRQ=3,4,5,7,10,11]; [IO=3E0h; IRQ=3,4,5,7,10,11]; [IO=2E0h; IRQ=3,4,5,7,10,11];

#### ► **Serial Port 6 Configuration**

Press [Enter] to make settings for the following items:

##### **Serial Port**

Use this item to enable or disable serial port (COM).

The optional settings: [Disabled]; [Enabled].

##### **Change Settings**

Use this item to select an optimal setting for super IO device.

The optional settings are: [IO=2E0h; IRQ=11]; [IO=3F8h; IRQ=3,4,5,7,10,11]; [IO=2F8h; IRQ=3,4,5,7,10,11]; [IO=3E8h; IRQ=3,4,5,7,10,11]; [IO=2E8h; IRQ=3,4,5,7,10,11]; [IO=3E0h; IRQ=3,4,5,7,10,11]; [IO=2E0h; IRQ=3,4,5,7,10,11];

### **WatchDog Reset Timer**

Use this item to support WDT reset function.

The optional settings: [Disabled]; [Enabled].

When set as [Enabled], the following sub-items shall appear:

#### **WatchDog Reset Timer Value**

User can set a value in the range of [4] to [255].

#### **WatchDog Reset Timer Unit**

The optional settings are: [Sec.]; [Min.]

When ERP Support is set to [Auto], users can set in the following items that appear:

### **ATX Power Emulate AT Power**

This item support Emulate AT power function, MB power On/Off control by power supply. Use needs to select 'AT or ATX Mode' on MB jumper at first (refer to JAT\_ATX jumper setting Pin 1&2 of for ATX Mode & Pin 2&3 of AT Mode Select).

### **Case Open Detect**

Use this item to detect case has already open or not, show message in POST.

The optional settings: [Disabled]; [Enabled].

When set as [Enabled], system will detect if COPEN has been short or not (*refer to **COPEN** jumper setting for Case Open Detection*); if Pin 1&2 of **COPEN** are short,

---

---

system will show Case Open Message during POST.

► **PC Health Status**

Press [Enter] to view current hardware health status, make further settings in 'SmartFAN Configuration' and set value in 'Shutdown Temperature'.

► **SmartFAN Configuration**

Press [Enter] to make settings for SmartFAN Configuration:

**SmartFAN Configuration**

**CPUFAN1/SYSFAN1/SYSFAN2 Smart Mode**

The optional settings: [Disabled]; [Enabled].

When set as **[Enabled]**, the following sub-items shall appear:

**CPUFAN1/SYSFAN1/SYSFAN2 Full-Speed Temperature**

Use this item to set CPUFAN full speed temperature. Fan will run at full speed when above this pre-set temperature.

**CPUFAN1/SYSFAN1/SYSFAN2 Full-Speed Duty**

Use this item to set CPUFAN full-speed duty. Fan will run at full speed when above this pre-set duty.

**CPUFAN1/SYSFAN1/SYSFAN2 Idle-Speed Temperature**

Use this item to set CPUFAN /SYSFAN idle speed temperature. Fan will run at idle speed when below this pre-set temperature.

**CPUFAN1/SYSFAN1/SYSFAN2 Idle-Speed Duty**

Use this item to set CPUFAN/SYSFAN idle speed duty. Fan will run at idle speed when below this pre-set duty.

► **Serial Port Console Redirection**

Press [Enter] to make settings for the following sub-items:

**COM1**

**Console Redirection**

Use this item to Console Redirection enable or disable.

The optional settings: [Disabled]; [Enabled].

When set as **[Enabled]**, user can make further settings in the 'Console Redirection Settings' screen:

► **Console Redirection Settings**

The settings specify how the host computer and the remote computer (which the user is using) will exchange data. Both computers should have the same or compatible settings.

Press [Enter] to make settings for the following sub-items:

**Terminal Type**

The optional settings: [VT100]; [VT100+]; [VT-UTF8]; [ANSI].

**[ANSI]**: Extended ASCII char set;

**[VT100]**: ASCII char set;

**[VT100+]**: Extends VT100 to support color, function keys, etc.;

**[VT-UTF8]**: Uses UTF8 encoding to map Unicode chars onto 1 or more bytes.

**Bits per second**

Use this item to select serial port transmission speed. The speed must be matched on the other side. Long or noisy lines may require lower speeds.

The optional settings: [9600]; [19200]; [38400]; [57600]; [115200].

**Data Bits**



---

---

The optional settings: [7]; [8].

### **Parity**

A parity bit can be sent with the data bits to detect some transmission errors.

The optional settings: [None]; [Even]; [Odd]; [Mark]; [Space].

**[Even]:** parity bit is 0 if the num of 1's in the data bits is even;

**[Odd]:** parity bit is 0 if num of 1's in the data bits is odd;

**[Mark]:** parity bit is always 1;

**[Space]:** parity bit is always 0;

**[Mark]** and **[Space]:** parity do not allow for error detection.

### **Stop Bits**

Stop bits indicate the end of a serial data packet. (A start bit indicates the beginning). The standard setting is 1 stop bit. Communication with slow devices may require more than 1 stop bit.

The optional settings: [1]; [2].

### **Flow Control**

Flow control can prevent data loss from buffer overflow. When sending data, if the receiving buffers are full, a "stop" signal can be sent to stop the data flow. Once the buffers are empty, a "start" signal can be sent to re-start the flow. Hardware flow control uses two wires to send start/stop signals.

The optional settings: [None]; [Hardware RTS/CTS].

### **VT-UTF8 Combo Key Support**

Use this item to enable VT-UTF8 Combination Key Support for ANSI/VT100 terminals.

The optional settings: [Disabled]; [Enabled].

### **Recorder Mode**

With this mode enable only text will be sent. This is to capture Terminal data.

The optional settings: [Disabled]; [Enabled].

### **Resolution 100x31**

Use this item to enable or disable extended terminal resolution.

The optional settings: [Disabled]; [Enabled].

### **Legacy OS Redirection Resolution**

On Legacy OS, the Number of Rows and Columns supported redirection.

The optional settings: [80x24]; [80x25].

### **Putty KeyPad**

Use this item to select Function Key and KeyPad on Putty.

The optional settings: [VT100]; [LINUX]; [XTERM6]; [SCO]; [ESCN]; [VT400].

## ► **Legacy Console Redirection Settings**

Press [Enter] to make settings for the following items:

### **Redirection COM Port**

Use this item to select a COM port to display redirection of Legacy OS and Legacy OPRM Messages

The optional settings: [COM1]

### **Resolution**

Use this item to on legacy OS, the number of rows and columns supported redirection

The optional settings: [80x24]; [80x25]

### **Redirect After POST**

When bootloader is selected, then legacy console redirection is disabled

---

---

before booting to legacy OS. When always enable is selected, the legacy console redirection is enabled for legacy OS. Default setting for this option is set to always enable.

The optional settings: [Always Enable]; [BootLoader]

**Serial Port for Out-of-Band Management/  
Windows Emergency Management Services (EMS)**

**Console Redirection EMS**

The optional settings: [Disabled]; [Enabled].

When set as **[Enabled]**, user can make further settings in ‘**Console Redirection Settings**’ screen:

► **Console Redirection Settings**

The settings specify how the host computer and the remote computer (which the user is using) will exchange data. Both computers should have the same or compatible settings.

Press [Enter] to make settings for the following sub-items.

**Terminal Type**

The optional settings: [VT100]; [VT100+]; [VT-UTF8]; [ANSI].

**[VT-UTF8]** is the preferred terminal type for out-of-band management. The next best choice is **[VT100+]** and then **[VT100]**. See above, in Console Redirection Settings page, for more help with Terminal Type/Emulation.

**Bits per second**

Use this item to select serial port transmission speed. The speed must be matched on the other side. Long or noisy lines may require lower speeds.

The optional settings: [9600]; [19200]; [57600]; [115200].

**Flow Control**

Flow control can prevent data loss from buffer overflow. When sending data, if the receiving buffers are full, a “stop” signal can be sent to stop the data flow. Once the buffers are empty, a “start” signal can be sent to re-start the flow. Hardware flow control uses two wires to send start/stop signals.

The optional settings: [None]; [Hardware RTS/CTS]; [Software Xon/Xoff].

**Data Bits EMS**

The default setting is: [8].

*\*This item may or may not show up, depending on different configuration.*

**Parity EMS**

The default setting is: [None].

*\*This item may or may not show up, depending on different configuration.*

**Stop Bits EMS**

The default setting is: [1].

*\*This item may or may not show up, depending on different configuration.*

► **USB Configuration**

Press [Enter] to make settings for the following sub-items:

**USB Configuration**

**XHCI Hand-off**

This is a workaround for OSES without XHCI hand-off support. The XHCI ownership change should be claimed by XHCI driver.

The optional settings: [Enabled]; [Disabled].

**USB Mass Storage Driver Support**

---

---

Use this item to enable or disable USB Mass storage driver support  
The optional settings: [Disabled]; [Enabled].

### **USB hardware delay and time-out**

#### **USB Transfer time-out**

Use this item to set the time-out value for control, bulk, and interrupt transfers.  
The optional settings: [1 sec]; [5 sec]; [10 sec]; [20 sec].

#### **Device reset time-out**

Use this item to set USB mass storage device start unit command time-out.  
The optional settings: [10 sec]; [20 sec]; [30 sec]; [40 sec].

#### **Device power-up delay**

Use this item to set maximum time the device will take before it properly reports itself to the host controller. 'Auto' uses default value: for a root port it is 100 ms, for a hub port the delay is taken from hub descriptor.

The optional settings: [Auto]; [Manual].

Select **[Manual]** you can set value for the following sub-item: '**Device power-up delay in seconds**', the delay range in from 1 to 40 seconds, in one second increments.

### ▶ **Network Stack Configuration**

Press [Enter] to go to '**Network Stack**' screen to make further settings.

#### **Network Stack**

Use this item to enable or disable UEFI Network Stack.

The optional settings: [Disabled]; [Enabled].

When set as **[Enabled]**, the following sub-items shall appear:

#### **IPv4 PXE Support**

Use this item to enable IPv4 PXE Boot Support. When set as [Disabled], IPv4 PXE boot option will not be created.

The optional settings: [Disabled]; [Enabled].

#### **IPv6 PXE Support**

Use this item to enable IPv6 PXE Boot Support. When set as [Disabled], IPv6 PXE boot option will not be created.

The optional settings: [Disabled]; [Enabled].

#### **PXE boot wait time**

Use this item to set wait time to press [ESC] key to abort the PXE boot.

#### **Media detect count**

Use this item to set number of times presence of media will be checked.

### ▶ **NVMe Configuration**

Use this item to NVMe Device options settings

### ▶ **Intel(R) Ethernet Controller(3) I225-LM - XX:XX:XX:XX:XX:XX**

This item shows current network brief information.

### ▶ **Intel(R) Ethernet Controller(3) I225-V - XX:XX:XX:XX:XX:XX**

This item shows current network brief information.


### ▶ **Intel(R) Ethernet Controller(3) I225-V - XX:XX:XX:XX:XX:XX**

This item shows current network brief information.

---

---

## 3-8 Chipset Menu



### ▶ **Memory Configuration**

#### **Maximum Memory Frequency**

Use this item to maximum memory frequency selections in Mhz

The optional settings are: [Auto]; [4000]; [4400] ; [4800] ; [5000] ; [5200] ; [5400] ; [5600]

### ▶ **Graphics Configuration**

Press [Enter] to make settings for the following sub-items:

#### **PCIe1 Slot**

Use this item to control the PCI Express root port

The optional settings: [Disabled]; [Enabled].

#### **PCIe1 Slot Lane Select**

The optional settings: [X16]; [X8/X8].

#### **Primary Display**

Use this item to select which graphics device should be primary display

The optional settings: [Auto]; [IGFX]; [PEG Slot]; [PCH PCIe]

#### **Internal Graphics**

Use this item to keep IGFX enabled based on the setup options

The optional settings: [Auto]; [Disabled]; [Enabled]

#### **Aperture Size**

Use this item to select the aperture size

Note: above 4GB MMIO BIOS assignment is automatically enabled when selecting 2048MB aperture to use this feature please disable CSM Support

The optional settings: [128MB]; [256MB]; [512MB]; [1024MB]

#### **DVMT Pre-Allocated**

Use this item to select DVMT 5.0 Pre-Allocated (Fixed) graphics memory size used by the internal graphics device

The optional settings: [32M]; [64M]; [128M]

#### **DVMT Total Gfx Mem**

Use this item to select DVMT 5.0 total graphic memory size used by the internal

---

---

graphics device

The optional settings: [128M]; [256M]; [Max]

► **VMD setup menu**

Press [Enter] to make settings for the following sub-items:

**Enable VMD controller**

Use this item to enable/disable to VMD controller

The optional settings: [Disabled]; [Enabled].

When set as [Enabled], the following sub-items shall appear:

**Enable VMD Global Mapping**

Use this item to enable/disable to VMD global mapping

The optional settings: [Disabled]; [Enabled].

When set as [Disabled], the following sub-items shall appear:

**Map this Root Port under VMD**

Use this item to Map/UnMap this root port to VMD

The optional settings: [Disabled]; [Enabled].

**Root Port BDF details**

► **PCH-IO Configuration**

Press [Enter] to make settings for the following sub-items:

**HD Audio**

Use this item to control detection of the HD-Audio device.

Disabled= HAD will be unconditionally disabled

Enabled= HAD will be unconditionally enabled

The optional settings: [Disabled]; [Enabled].

**Onboard Lan1 Controller**

Use this item to enable or disable onboard NIC.

The optional settings: [Enabled]; [Disabled].

**Onboard Lan2 Controller**

Use this item to enable or disable Device or Controller.

The optional settings: [Disabled]; [Enabled].

**Onboard Lan3 Controller**

Use this item to enable or disable Device or Controller.

The optional settings: [Disabled]; [Enabled].


**System State after Power Failure**

Use this item to specify what state to go to when power re-applied after a power failure (G3 state).

The optional settings: [Always Off]; [Always On]; [Former State].

---

## 3-9 Security Menu



Security menu allow users to change administrator password and user password settings.

### Administrator Password

If there is no password present on system, please press [Enter] to create new administrator password. If password is present on system, please press [Enter] to verify old password then to clear/change password. Press again to confirm the new administrator password.

### User Password

If there is no password present on system, please press [Enter] to create new user password. If password is present on system, please press [Enter] to verify old password then to clear/change password. Press again to confirm the new user password.

#### ► Secure Boot

Press [Enter] to make customized secure settings:

#### System Mode

##### Secure Boot

Secure Boot feature is Active if Secure Boot is Enabled, Platform Key(PK) is enrolled and the System is in User mode. The mode change requires platform reset.

The optional settings: [Disabled]; [Enabled].

##### Secure Boot Mode

Set UEFI Secure Boot Mode to Standard mode or Custom mode. This change is effective after save. After reset, this mode will return to Standard mode.

In Custom mode, Secure Boot Policy variables can be configured by a physically present user without full authentication.

The optional settings: [Standard]; [Custom].

When set as [**Custom**], user can make further settings in the following items that show up:

#### ► Restore Factory Keys

Use this item to force system to User Mode, to install factory default Secure Boot

---

---

key databases.

▶ **Reset To Setup Mode**

Use this item to delete all Secure Boot key databases from NVRAM.

▶ **Key Management**

This item enables expert users to modify Secure Boot Policy variables without full authentication, which includes the following items:

**Vendor Keys**

**Factory Key Provision**

This item is for user to install factory default Secure Boot keys after the platform reset and while the System is in Setup mode.

The optional settings: [Disabled]; [Enabled].

▶ **Restore Factory Keys**

Use this item to force system into User Mode. Install factory default Secure Boot key databases.

▶ **Reset To Setup Mode**

Use this item to delete all Secure Boot key databases from NVRAM.

▶ **Export Secure Boot variables**

Use this item to copy NVRAM content of Secure Boot variables to files in a root folder on a file system device.

▶ **Enroll Efi Image**

This item allows the image to run in Secure Boot mode.

Enroll SHA256 Hash certificate of a PE image into Authorized Signature Database (db).

**Device Guard Ready**

▶ **Remove 'UEFI CA' from DB**

▶ **Restore DB defaults**

Use this item to restore DB variable to factory defaults.

**Secure Boot variable/Size/Keys/Key Source**

▶ **Platform Key(PK)/Key Exchange Keys/Authorized Signatures/Forbidden Signatures/ Authorized TimeStamps/OsRecovery Signatures**

Use this item to enroll Factory Defaults or load certificates from a file:

1. Public Key Certificate:


- a) EFI\_SIGNATURE\_LIST
- b) EFI\_CERT\_X509 (DER)
- c) EFI\_CERT\_RSA2048 (bin)
- d) EFI\_CERT\_SHAXXX

2. Authenticated UEFI Variable

3. EFI PE/COFF Image (SHA256)

Key Source: Factory, External, Mixed

## 3-10 Boot Menu




### Boot Configuration

- ▶ **Setup Prompt Timeout**  
Use this item to set number of seconds to wait for setup activation key.
- ▶ **Bootup Numlock State**  
Use this item to select keyboard numlock state.  
The optional settings are: [On]; [Off].
- ▶ **Quiet Boot**  
The optional settings are: [Disabled]; [Enabled].  
When set as [Enabled], user can make settings in the following items that appear:

### Boot Option Priorities

## 3-11 Save & Exit Menu






- 
- ▶ **Save Changes and Reset**  
This item allows user to reset the system after saving the changes.
  - ▶ **Discard Changes and Reset**  
This item allows user to reset the system without saving any changes.
  - ▶ **Restore Defaults**  
Use this item to restore /load default values for all the setup options.
  - ▶ **Save as User Defaults**  
Use this item to save the changes done so far as user defaults.
  - ▶ **Restore User Defaults**  
Use this item to restore defaults to all the setup options.

### **Boot Override**

## **3-12 MEBx**



- ▶ **Intel(R) ME Password**  
Use this item to MEBx Login.