

# ***MI23 Series***

## ***User's Manual***

**NO. G03-MI23-F**

**Revision: 4.0**

**Release date: July 9, 2024**

### **Trademark:**

- \* Specifications and Information contained in this documentation are furnished for information use only, and are subject to change at any time without notice, and should not be construed as a commitment by manufacturer.**

---

## Environmental Protection Announcement

Do not dispose this electronic device into the trash while discarding. To minimize pollution and ensure environment protection of mother earth, please recycle.



---

# **TABLE OF CONTENT**

ENVIRONMENTAL SAFETY INSTRUCTION.....	iii
USER'S NOTICE .....	iv
MANUAL REVISION INFORMATION .....	iv
ITEM CHECKLIST .....	iv
CHAPTER 1 INTRODUCTION OF THE MOTHERBOARD	
1-1 FEATURE OF MOTHERBOARD .....	1
1-2 SPECIFICATION .....	2
1-3 LAYOUT DIAGRAM .....	4
CHAPTER 2 HARDWARE INSTALLATION	
2-1 JUMPER SETTING.....	10
2-2 CONNECTORS AND HEADERS .....	13
2-2-1 CONNECTORS.....	13
2-2-2 HEADERS.....	19
2-3 MAXIMUM VOLTAGE & CURRENT LIMIT .....	23
CHAPTER 3 INTRODUCING BIOS	
3-1 ENTERING SETUP.....	24
3-2 BIOS MENU SCREEN.....	25
3-3 FUNCTION KEYS.....	26
3-4 GETTING HELP .....	26
3-5 MENU BAR.....	27
3-6 MAIN MENU .....	27
3-7 ADVANCED MENU .....	28
3-8 CHIPSET MENU.....	40
3-9 SECURITY MENU .....	43
3-10 BOOT MENU .....	46
3-11 SAVE & EXIT MENU .....	47
3-12 MEBX.....	48



## Environmental Safety Instruction

---

- Avoid the dusty, humidity and temperature extremes. Do not place the product in any area where it may become wet.
- 0 to 40 centigrade is the suitable temperature. (The temperature comes from the request of the chassis and thermal solution)
- Generally speaking, dramatic changes in temperature may lead to contact malfunction and crackles due to constant thermal expansion and contraction from the welding spots' that connect components and PCB. Computer should go through an adaptive phase before it boots when it is moved from a cold environment to a warmer one to avoid condensation phenomenon. These water drops attached on PCB or the surface of the components can bring about phenomena as minor as computer instability resulted from corrosion and oxidation from components and PCB or as major as short circuit that can burn the components. Suggest starting the computer until the temperature goes up.
- The increasing temperature of the capacitor may decrease the life of computer. Using the close case may decrease the life of other device because the higher temperature in the inner of the case.
- Attention to the heat sink when you over-clocking. The higher temperature may decrease the life of the device and burned the capacitor.

---

# USER’S NOTICE

COPYRIGHT OF THIS MANUAL BELONGS TO THE MANUFACTURER. NO PART OF THIS MANUAL, INCLUDING THE PRODUCTS AND SOFTWARE DESCRIBED IN IT MAY BE REPRODUCED, TRANSMITTED OR TRANSLATED INTO ANY LANGUAGE IN ANY FORM OR BY ANY MEANS WITHOUT WRITTEN PERMISSION OF THE MANUFACTURER.

THIS MANUAL CONTAINS ALL INFORMATION REQUIRED TO USE THIS MOTHER-BOARD SERIES AND WE DO ASSURE THIS MANUAL MEETS USER’S REQUIREMENT BUT WILL CHANGE, CORRECT ANY TIME WITHOUT NOTICE. MANUFACTURER PROVIDES THIS MANUAL “AS IS” WITHOUT WARRANTY OF ANY KIND, AND WILL NOT BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES (INCLUDING DAMAGES FOR LOSS OF PROFIT, LOSS OF BUSINESS, LOSS OF USE OF DATA, INTERRUPTION OF BUSINESS AND THE LIKE).

PRODUCTS AND CORPORATE NAMES APPEARING IN THIS MANUAL MAY OR MAY NOT BE REGISTERED TRADEMARKS OR COPYRIGHTS OF THEIR RESPECTIVE COMPANIES, AND THEY ARE USED ONLY FOR IDENTIFICATION OR EXPLANATION AND TO THE OWNER’S BENEFIT, WITHOUT INTENT TO INFRINGE.

## Manual Revision Information

Reversion	Revision History	Date
4.0	Fourth Edition	July 9, 2024

## Item Checklist

- ☒ Motherboard
- ☒ Cable(s)

---

# Chapter 1

## Introduction of the Motherboard

### 1-1 Feature of Motherboard

- Intel® LGA1700 Socket supports 12<sup>th</sup> /13<sup>th</sup> /14<sup>th</sup> Gen. Core Processor **(Max. 65W TDPs under 180A)**
- Support 2\* DDR5 4800MHz SO-DIMM up to 96GB
- **MI23-Q670X/R680X series:** total support up to 8\* 2.5GbE RJ-45 LAN ports
- **MI23-H610X series:** total support up to 6\* 2.5GbE RJ-45 LAN ports
- **MI23-Q670X/R680X series:** total support up to 2\* USB3.2 (Gen.2), 2\* USB3.2 (Gen.1), 4\* USB2.0 ports
- **MI23-H610X series:** total support up to 2\* USB3.2 (Gen.2), 1\* USB3.2 (Gen.1), 5\* USB2.0 ports
- **MI23-Q670X/R680X series:** 4 \* SATAIII (6Gb/s) ports with support for RAID 0, 1, 5, 10 mode & 2\* M.2 (M-key) slots; 1\* M.2 (E-key) & 1\* M.2 (B-key) slot along with SIM card holder; 1\* sideways PCIE Gen.4 x4 slot
- **MI23-H610X series:** 4 \* SATAIII (6Gb/s) ports & 1\* M.2 (M-key) slot; 1\* M.2 (E-key) & 1\* M.2 (B-key) slot along with SIM card holder
- 1 \* internal HDMI port
- Support JetBIOS SW back up tool for BIOS recovering
- Support onboard TPM 2.0 (**\*optional**)
- Support Smart FAN function
- Supports ACPI S3 Function
- Compliance with ErP Standard
- Support Watchdog Timer Technology

## 1-2 Specification

Spec	Description
Design	<ul style="list-style-type: none"> <li>● Mini-ITX form factor; 10-layers;</li> <li>● PCB size: 17.0x17.0cm</li> </ul>
Chipset	<ul style="list-style-type: none"> <li>● <b>MI23-H610X Series:</b> Intel H610E Chipset</li> <li>● <b>MI23-Q670X Series:</b> Intel Q670E Chipset</li> <li>● <b>MI23-R680X Series:</b> Intel R680E Chipset</li> </ul>
CPU Socket	<ul style="list-style-type: none"> <li>● Intel LGA 1700 Socket supports 12<sup>th</sup> /13<sup>th</sup> /14<sup>th</sup> Gen. Core™ i7 processors, Intel® Core™ i5 processors, Intel® Core™ i3 processors, Intel® Pentium™ processors, Intel® Celeron™ processors (<b>Max.65W TDPs under 180A</b>)</li> </ul> <p><i>*Note: for detailed CPU support information please visit our website.</i></p>
Memory Slot	<ul style="list-style-type: none"> <li>● 2* DDR5 SO-DIMM slot</li> <li>● Support 2* DDR5 4800MHz SO-DIMM up to 96GB</li> <li>● Support dual channel function</li> </ul> <p><i>*Note: MI23-R680X series support ECC.</i></p>
Expansion Slot	<ul style="list-style-type: none"> <li>● <b>*PCIE2:</b> 1* PCIE Gen.4 x4 slot by sideways</li> </ul> <p><i>*Note: 1.PCIE2 slot is only available to MI23-Q670X/R680X series; 2.PCIE2 can be expanded to support up to 4* PCIe signal 4 by 1 slots (At present, this function only supported by ETC4G adapter card).</i></p> <ul style="list-style-type: none"> <li>● <b>M2E1:</b> 1* M.2 E-key, type-2230, USB2.0/PCIe x1 interface supports CNVi</li> <li>● <b>M2B1:</b> 1* M.2 B-key, type-3042, USB3.2 Gen.1/USB2.0/PCIe x1 interface supports 4G Module</li> <li>● <b>SIMCARDB1:</b> Nano-SIM card slot; co-function with M2B1 slot</li> </ul>
Storage	<ul style="list-style-type: none"> <li>● <b>SATA1/2/3/*4:</b> 4* SATAIII 6Gb/s port (<b>*SATA4 shares with M2M1</b>)</li> </ul> <p><i>*Note: MI23-Q670X/R680X series support RAID 0/1/5/10 mode.</i></p> <ul style="list-style-type: none"> <li>● <b>M2M1:</b> 1* M.2 M-key, type-2280 slot (for <b>MI23-Q670X/R680X series: PCIe Gen.4 x4 supports NVMe w/SATA interface; for MI23-H610X series: only SATA interface only</b>).</li> <li>● <b>*M2M2:</b> 1* M.2 M-Key, type-2242/2280 slot (PCIe Gen.4 x4 supports NVMe w/SATA interface )</li> </ul> <p><i>*Note: M2M2 slot is only available to MI23-Q670X/R680X series.</i></p>
LAN Chips	<ul style="list-style-type: none"> <li>● <b>MI23-Q670X/R680X:</b> 1* Intel i225-LM 2.5GbE + 7* Intel i225-V 2.5GbE</li> <li>● <b>MI23-H610X:</b> 6* Intel i225-V 2.5GbE</li> </ul> <p><i>*Note: 2500Mbps high-speed transmission rate is only supported over CAT</i></p>

	5e UTP cable.
<b>Graphics</b>	● Intel UHD Graphics
<b>BIOS</b>	● AMI 256M Flash ROM
<b>Multi I/O</b>	<p><b>Rear Panel I/O:</b></p> <ul style="list-style-type: none"> <li>● 1* Power on/off button</li> <li>● 1* Power LED &amp; 1* HDD LED</li> <li>● 1* RJ-45 RS232 COM port</li> <li>● <b>MI23-Q670X/R680X:</b> 2* USB 3.2 Gen.2 port &amp; 2* USB 3.2 Gen.1 port</li> <li>● <b>MI23-H610X:</b> 2* USB 3.2 Gen.2 port &amp; 1* USB 3.2 Gen.1 port +1* USB 2.0 port</li> <li>● <b>MI23-Q670X/R680X:</b> 8* 2.5GbE RJ-45 port</li> <li>● <b>MI23-H610X:</b> 6* 2.5GbE RJ-45 port</li> </ul> <p><b>Internal I/O Connectors &amp; Headers:</b></p> <ul style="list-style-type: none"> <li>● 1 *24-pin main power connector</li> <li>● 1 *4-pin 12V power connector</li> <li>● 1* CPUFAN connector &amp; 1* SYSFAN connector</li> <li>● 1* CMOS battery connector</li> <li>● 1* Front panel header</li> <li>● 1* HDMI header</li> <li>● 2* RS232 COM port header</li> <li>● 2 * 9-Pin USB 2.0/1.1 header for 4* USB 2.0/1.1 port</li> <li>● 2* LAN Status LED header</li> <li>● 1* GPIO header</li> <li>● 1* PS2 Keyboard &amp; Mouse header</li> <li>● 1* SMBUS header</li> </ul>
<b>TPM 2.0</b>	● Optional for <b>MI23-R6802, MI23-Q6702 &amp; MA20-H6102</b> Series
<b>OS Support</b>	● <i>for detailed OS support information please visit our website for latest update</i>




---


## 1-3 Layout Diagram

### *Rear IO Diagram*

***For MI23-Q670X / MI23-R680X Series:***




***For MI23-H610X Series:***



# Motherboard Internal Diagram-Front


MI23-Q670X/R680X Series:



**\* Note:** PCIE2 can be expanded to support up to 4\* PCIe signal 4 by1 slots (At present, this function only supported by ETC4G adapter card series).


# Motherboard Internal Diagram-Front

## MI23-H610X Series:



---


## Motherboard Internal Diagram-Back



**\*Note:** 1. SIM card slot (only workable along with M.2 B-key slot); 2. **PCIE2** sideways **PCI Express Gen.4 x4** slot (only on **MI23-Q670X/R680X**) can be expanded to support up to 4\* PCIe signal 4 by1 slots (At present, only supported by **ETC4G adapter card** series ); 3. **M2M2** Slot (only on **MI23-Q670X/R680X**).

---

## Motherboard Jumper Position



**\*Note:** The diagrams in the manual are mostly taken from **MI23-Q670X/R680X** series unless otherwise stated.

---

## Connectors

Connector	Name
RJ45_COM1	RJ-45 COM Port Connector for Console
USB31	USB 3.2 (Gen.2) Port X2
<b>MI23-Q670X/R680X: USB32</b>	USB 3.2 (Gen.1) Port X2
<b>MI23-H610X: USB32</b>	<b>Top:</b> USB 2.0 Port <b>Bottom:</b> USB 3.2(Gen.1) Port
LAN1-4	2.5 GbE RJ-45 LAN Port X4
<b>MI23-Q670X/R680X: LAN5-8</b>	2.5 GbE RJ-45 LAN Port X4
<b>MI23-H610X: LAN5-8</b>	2.5 GbE RJ-45 LAN Port X2
ATXPWR1	Main Power Connector
ATX12V	Internal 12V Power Connector
SATA1/2/3/4	SATAIII Connector
CPUFAN	CPU Fan Connector
SYSFAN	System Fan Connector
BATCON	CMOS Battery Connector

## Headers

Header	Name	Description	Pitch
JW_FP	Front Panel Header(PWR LED/ HD LED/Power Button /Reset)	9-pin Block	2.54mm
HDMI1	HDMI Port Header	19-pin Block	2.0mm
FP_COM2/3	RS232 Serial Port Header	9-pin Block	2.0mm
FP_USB21/22	USB2.0 Port Header X2	9-pin Block	2.0mm
LAN_LED1	LAN Status LED Header	8-pin Block	2.54mm
<b>MI23-Q670X/R680X: LAN_LED2</b>	<i>LAN Status LED Header</i>	<i>8-pin Block</i>	2.54mm
<b>MI23-H610X: LAN_LED2</b>	<i>LAN Status LED Header</i>	<i>4-pin Block</i>	2.54mm
GPIO	GPIO Port Header	10-pin Block	2.0mm
PS2KBMS	PS2 Keyboard & Mouse Header	6-pin Block	2.0mm
SMBUS	SMBUS Header	5-pin Block	2.0mm


## Jumper

Jumper	Name	Description	Pitch
JPCOM1	RJ45_COM1 Port Pin-5 VCC Select	4-pin Block	2.0mm
JPME_DIS	ME Disabled	2-pin Block	2.0mm
COPEN	Case Open Message Display Function	2-pin Block	2.54mm
JAT_ATX	ATX Mode / AT Mode Select	3-pin Block	2.0mm
JBAT	Clear CMOS RAM Settings	3-pin Block	2.0mm
JP80P	GPIO Header Function Select	2-pin Block	2.0mm

# Chapter 2 Hardware Installation


## 2-1 Jumper Setting

**JPCOM1 (4-pin): RJ45\_COM1 Port Pin5 VCC Select**




**\*Note:** Please make sure you set Pin (2-4) of Jumper **JPCOM1** as closed from beginning or you will cause the short circuit with the general Console cable to **RJ45-COM1** port (refer to **page-14**).


### ***JPME\_DIS(2-pin): ME Features Select***



***JPME\_DIS → ME Disable***




***1-2 Open: Normal;***




***1-2 Closed: Disable ME Features.***

### ***COPEN (2-pin): Case Open Message Display Function***



***COPEN → Case Open Detection***




**Pin 1-2 Short:** When Case open function pin short to GND, the Case open function was detected. When Used, needs to enter BIOS and enable 'Case Open Detect' function. In this case if your



case is removed, next time when you restart your computer, a message will be displayed on screen to inform you of this.

### **JAT\_ATX (3-pin): AT Mode /ATX Mode Select**



**JAT\_ATX→ATX/AT Mode Select**



1 3

**1-2 Closed: ATX Mode Selected;**




1 3

**2-3 Closed: AT Mode Selected.**

**\*ATX Mode Selected:** Press power button to power on after power input ready;

**AT Mode Selected:** Directly power on as power input ready.

### **JBAT (3-pin): Clear CMOS RAM Settings**



**JBAT→Clear CMOS RAM Settings**



1 3


**1-2 Closed: Normal;**



1 3

**2-3 Closed: Clear CMOS.**

## JP80P(2-pin): GPIO Header Function Select



### JP80P→GPIO Function Select

Pin1 →

1-2 Open: Function as 80Port;

Pin1 →




1-2 Closed: Function as GPIO Port.

## 2-2 Connectors and Headers


### 2-2-1 Connectors

#### Rear I/O Back Panel Connectors


Icon	Name	Function
	Power Button	For user to power on/off the system.
	RJ-45 RSS232 COM Port	This connector is a RJ-45 COM port for console function.
	USB 3.2 (Gen.2) Port	To connect USB keyboard, mouse or other devices compatible with USB 3.2 (Gen.2) specification. Ports support up to 10Gbps data transfer rate.

	<b>USB 2.0 Port</b>	To connect USB keyboard, mouse or other devices compatible with USB 2.0 specification.
	<b>USB 3.2 (Gen.1) Port</b>	To connect USB keyboard, mouse or other devices compatible with USB 3.2 (Gen.1) specification. Ports support up to 5Gbps data transfer rate.
	<b>2.5Gbps RJ-45 LAN Port</b>	This connector is standard RJ-45 LAN jack for Network connection which supports 10/100/1000/2500 Mbps Ethernet data transfer rate. ( <i>*Note: 2.5Gbps is only supported with CAT 5e UTP cable</i> ).

**(1) RJ45\_COM1(8-pin block): RJ-45 COM Port Connector for Console**




(2) 2.5 Gbps RJ-45 Ethernet LAN Port Connector



LAN1/LAN2/ LAN3/LAN4/ LAN5/ LAN6/\* LAN7/\* LAN8

2.5Gbps RJ-45 LAN port LED Signals:

\*\* There are two LED next to the LAN port. Please refer to the table below for the LAN port LED indications.



**A: Activity/Link LED**



Status	Description
Off	No Link
Blinking	Data Activity
On	Link

**B: Speed LED**

Status	Description
Off	10/100Mbps connection
Orange	1Gbps connection
Green	2.5Gbps connection



\* **Note:** 2.5Gbps high-speed transmission rate is **only** supported over **CAT 5e UTP cable**;  
**MI23-Q670X/R680X Series:** total support 8\* 2.5GbE RJ-45 port;  
**MI23-H610X Series:** total support 6\* 2.5GbE RJ-45 port(without LAN7/LAN8).

**(3) ATXPWR(24-pin block): Main Power Connector**



PIN	ROW1	ROW2
1	+3.3V	+3.3V
2	+3.3V	-12V
3	GND	GND
4	+5V	Soft Power on
5	GND	GND
6	+5V	GND
7	GND	GND
8	Power OK	-5V
9	+5V Stand by	+5V
10	+12V	+5V
11	+12V	+5V
12	+3.3V	GND

**(4) ATX12V (4-pin block): 12V Internal Power Connector**




Pin No.	Definition
1	GND
2	GND
3	+12V
4	+12V

---

**(5) SATA1/2/3/4 (7-pin): SATA III Port connector**

*These are high-speed SATAIII port that supports 6 GB/s transfer rate.*





Pin No.	Definition
1	GND
2	TXP
3	TXN
4	GND
5	RXN
6	RXP
7	GND




**(6) CPUFAN (4-pin): CPU FAN Connector**

**CPUFAN**




---

**(7) SYSFAN (3-pin): System FAN Connector**




**(8) BATCON (2-pin): Battery Connector**




## 2-2-2 Headers

### JW\_FP (9-pin): Front Panel Header





**JW\_FP**



### HDMI1 (19-pin): HDMI Port Header


**HDMI1**






---



## FP\_COM2/ FP\_COM 3 (9-pin): RS232 Serial Port Header



## FP\_USB21/ FP\_USB22 (9-pin): USB 2.0 Port Headers



## LAN\_LED1 (8-pin): LAN1 & LAN2& LAN3 & LAN4 Activity LED Header





*LAN\_LED1 Header*

## LAN\_LED2 (8-pin/4-pin): LAN5 & LAN6& LAN7 & LAN8 Activity LED Header


For **MI23-Q670X/R680X** Series: 8-pin LAN\_LED2 Header;

For **MI23-H610X** Series: 4-pin LAN\_LED2 Header (without Pin5/6/7/8 for LAN7/LAN8).




*LAN\_LED2 Header*


### GPIO (10-pin): GPIO Header




**GPIO**




### PS2KBMS (6-pin): PS/2 Keyboard & Mouse Header



**PS2KBMS**



## SMBUS1 (5-Pin): SMBUS Header



## 2-3 Maximum Voltage & Current Limit

Below is a list of maximum voltage & Current Limit specification for motherboard interface (including but not limited to slots, connectors and headers) for setup reference:

Parts		Working Voltage	Current Support
USB Ports from	<b>USB31</b>	5V	1.5A
	<b>USB32</b>	5V	1.5A
	<b>FP_USB21</b>	5V	1.5A
	<b>FP_USB22</b>	5V	1.5A
<b>JW_FP</b>		5V	1A
<b>RJ45_COM1</b>		5V/12V(via jumper setting)	0.5A
<b>FP_COM2/ FP_COM3</b>		5V/12V(via jumper setting)	0.5A
<b>LAN_LED1/LAN_LED2</b>		3.3V	0.3A
<b>GPIO</b>		5V	1A
<b>PS2KBMS</b>		5V	0.5A
<b>SMBUS1</b>		3.3V	0.5A
<b>CPUFAN1/ SYSFAN</b>		12V	1.5A

---

# Chapter 3

## Introducing BIOS


**Notice!** The BIOS options in this manual are for reference only. Different configurations may lead to difference in BIOS screen and BIOS screens in manuals are usually the first BIOS version when the board is released and may be different from your purchased motherboard. Users are welcome to download the latest BIOS version from our official website.

The BIOS is a program located on a Flash Memory on the motherboard. This program is a bridge between motherboard and operating system. When you start the computer, the BIOS program will gain control. The BIOS first operates an auto-diagnostic test called POST (power on self test) for all the necessary hardware, it detects the entire hardware device and configures the parameters of the hardware synchronization. Only when these tasks are completed done it gives up control of the computer to operating system (OS). Since the BIOS is the only channel for hardware and software to communicate, it is the key factor for system stability, and in ensuring that your system performance as its best.

### 3-1 Entering Setup


Power on the computer and by pressing <Del> immediately allows you to enter Setup. If the message disappears before your respond and you still wish to enter Setup, restart the system to try again by turning it OFF then ON or pressing the “RESET” button on the system case. You may also restart by simultaneously pressing <Ctrl>, <Alt> and <Delete> keys. If you do not press the keys at the correct time and the system does not boot, an error message will be displayed and you will again be asked to

Press **<Del>** to enter Setup



### 3-2 BIOS Menu Screen

The following diagram show a general BIOS menu screen:



BIOS Menu Screen

---

## 3-3 Function Keys

In the above BIOS Setup main menu of, you can see several options. We will explain these options step by step in the following pages of this chapter, but let us first see a short description of the function keys you may use here:

- Press ←→ (left, right) to select screen;
- Press ↑↓ (up, down) to choose, in the main menu, the option you want to confirm or to modify.
- Press <Enter> to select.
- Press <+>/<-> keys when you want to modify the BIOS parameters for the active option.
- [F1]: General help.
- [F2]: Previous value.
- [F3]: Optimized defaults.
- [F4]: Save & Reset.
- Press <Esc> to quit the BIOS Setup.

## 3-4 Getting Help

### Main Menu

The on-line description of the highlighted setup function is displayed at the top right corner the screen.

### Status Page Setup Menu/Option Page Setup Menu

Press [F1] to pop up a small help window that describes the appropriate keys to use and the possible selections for the highlighted item. To exit the Help Window, press <Esc>.

---

## 3-5 Menu Bars


There are six menu bars on top of BIOS screen:

<b>Main</b>	To change system basic configuration
<b>Advanced</b>	To change system advanced configuration
<b>Chipset</b>	To change chipset configuration
<b>Security</b>	Password settings
<b>Boot</b>	To change boot settings
<b>Save &amp; Exit</b>	Save setting, loading and exit options.

User can press the right or left arrow key on the keyboard to switch from menu bar. The selected one is highlighted.

## 3-6 Main Menu

Main menu screen includes some basic system information. Highlight the item and then use the <+> or <-> and numerical keyboard keys to select the value you want in each item.






## System Date

Set the date. Please use [Tab] to switch between date elements.

## System Time

Set the time. Please use [Tab] to switch between time elements.

## 3-7 Advanced Menu



### ▶ Connectivity Configuration

Press [Enter] to make settings for the following sub-item:

#### **CNVi Mode**

This option configures connectivity.

[Auto Detection] means that if Discrete solution is discovered it will be enabled by default. Otherwise integrated solution (CNVi) will be enabled ;

[Disable Integrated] disables Integrated solution

The optional settings are: [Disable Integrated]; [Auto Detection]

### ▶ CPU Configuration

Press [Enter] to view current CPU configuration and make settings for the following

---

sub-items:

**Hyper-Threading**

Use this item to enable or disable Hyper-Threading Technology

The optional settings: [Disabled]; [Enabled].

**Intel (VMX) Virtualization Technology**

When enabled, a VHM can utilize the additional hardware capabilities provided by Vanderpool Technology.

The optional settings: [Disabled]; [Enabled].

**Intel (R) SpeedStep™**

Use this item to Allows more than two frequency ranges to be supported.

The optional settings: [Disabled]; [Enabled].

**C states**

Use this item to enable/disable CPU Power management. Allows CPU to go to C states when it's not 100% utilized.

The optional settings: [Disabled]; [Enabled].

**Turbo Mode**

Use this item to enable/disable processor turbo mode (requires EMTTM enabled too). AUTO means enabled.

The optional settings: [Disabled]; [Enabled].

► **SATA Configuration**

Press [Enter] to make settings for the following sub-items:

**SATA Controller(s)**

The optional settings are: [Enabled]; [Disabled].

When set as [Enabled], the following sub-items shall appear:

**M.2(M2M2)**

**Port**

Use this item to enable or disable SATA Port

The optional settings are: [Enabled]; [Disabled].

**SATA1/2/3/4/M.2(M2M1)**

**Port**

Use this item to enable or disable SATA Port

The optional settings are: [Enabled]; [Disabled].

**Hot Plug**

---

Use this item to designate this port as Hot Pluggable.

The optional settings are: [Enabled]; [Disabled].

► **PCH-FW Configuration**

Use this item to configure Management engine technology parameters

Press [Enter] to make settings for the following sub-items:

**TPM Device Selection**

Use this item to select TPM device: PTT or dTPM. PTT- Enables PTT in SkuMgr  
dTPM 1.2 – Disables PTT in SkuMgr Warning! PTT/dTPM will be disabled and all  
data saved on it will be lost

The optional settings are: [dTPM]; [PTT].

► **Firmware Update Configuration**

Use this item to configure management engine technology parameters.

**Me FW Image Re-Flash**

Use this item to enable/disable Me FW Image Re-Flash function

The optional settings: [Disabled]; [Enabled]

► **Trusted Computing**

Press [Enter] to view ME information and make settings in the following sub-items:

**Security Device Support**

Use this item to enable or disable BIOS support for security device. O.S will not  
show security device. TCG EFI protocol and INT1A interface will not be available.

The optional settings: [Disabled]; [Enabled].

When set as [Enabled], user can make settings in the following items that appear:

**Pending operation**

Use this item to schedule an operation for the security device. NOTE: Your computer  
will reboot during restart in order to change state of security device

The optional settings: [None]; [TPM Clear].

**TPM Device Selection**

Use this item to select TPM device: PTT or dTPM. PTT-Enables PTT in SkuMgr  
dTPM 1.2 – Disables PTT in SkuMgr Warning! PTT/dTPM will be disabled and all  
data saved on it will be lost

The optional settings: [dTPM]; [PTT].

► **ACPI Settings**

Press [Enter] to make settings for the following sub-items:

---

## **ACPI Settings**

### **ACPI Sleep State**

Use this item to select the highest ACPI sleep state the system will enter when the suspend button is pressed.

The optional settings are: [Suspend Disabled]; [S3 (Suspend to RAM)].

### **► Wake-up Function Settings**

#### **Wake-up System With Fixed Time**

Use this item to enable or disable system wake on alarm event. When enabled, system will wake on the hr: min: sec specified

The optional settings: [Disabled]; [Enabled].

When set as [Enabled], user can make settings in the following items that appear:

#### **Wake-up Hour**

Use this item to select 0-23 for example enter 3 for 3am and 15 for 3pm

#### **Wake-up Minute**

Use this item to select 0-59

#### **Wake-up Second**

Use this item to select 0-59

#### **Wake-up System with Dynamic Time**

*\*This item will only show when 'Wake-up System With Fixed Time' is set as [Disabled].*

Use this item to enable or disable system wake on alarm event. When enabled, system will wake on the current time + Increase minute(s)

When set as [Enabled], user can make settings in the following items that appear:

#### **Wake-up Minute Increase**

Use this item to select 1-60

#### **PS2 KB/MS Wake-up**

Use this item to enable or disable PS2 KB/MS Wake-up from (S3/S4/S5) Support only disable ERP function

The optional settings: [Disabled]; [Enabled].

#### **PCIe Wake-up from S3-S5**

The optional settings: [Disabled]; [Enabled].

#### **USB S3/S4 Wake-up**

Use this item to enable or disable USB S3/S4 Wake-up Support only disable ERP

---

function

The optional settings: [Disabled]; [Enabled].

### **USB S5 Power**

Use this item to USB Power after system shutdown support only disable ERP function

The optional settings: [Disabled]; [Enabled].

### ▶ **Super IO Configuration**

Press [Enter] to make settings for the following sub-items:

#### **Super IO Configuration**

#### **ERP Support**

Use this item to energy-related products function. Disable ERP to active all wake-up functions.

The optional settings: [Disabled]; [Auto].

### ▶ **Serial Port 1 Configuration**

Press [Enter] to make settings for the following items:

#### **Serial Port**

Use this item to enable or disable serial port (COM).

The optional settings: [Disabled]; [Enabled].

#### **Change Settings**

Use this item to select an optimal setting for super IO device.

The optional settings are: [IO=3F8h; IRQ=4]; [IO=3F8h; IRQ=3,4,5,7,10,11];  
[IO=2F8h; IRQ=3,4,5,7,10,11]; [IO=3E8h; IRQ=3,4,5,7,10,11]; [IO=2E8h;  
IRQ=3,4,5,7,10,11];

### ▶ **Serial Port 2 Configuration**

Press [Enter] to make settings for the following items:

#### **Serial Port**

Use this item to enable or disable serial port (COM).

The optional settings: [Disabled]; [Enabled].

#### **Change Settings**

Use this item to select an optimal setting for super IO device.

The optional settings are: [IO=2F8h; IRQ=3]; [IO=3F8h; IRQ=3,4,5,7,10,11];  
[IO=2F8h; IRQ=3,4,5,7,10,11]; [IO=3E8h; IRQ=3,4,5,7,10,11]; [IO=2E8h;  
IRQ=3,4,5,7,10,11];

---

► **Serial Port 3 Configuration**

Press [Enter] to make settings for the following items:

**Serial Port**

Use this item to enable or disable serial port (COM).

The optional settings: [Disabled]; [Enabled].

**Change Settings**

Use this item to select an optimal setting for super IO device.

The optional settings are: [IO=3E8h; IRQ=10]; [IO=3F8h; IRQ=3,4,5,7,10,11];

[IO=2F8h; IRQ=3,4,5,7,10,11]; [IO=3E8h; IRQ=3,4,5,7,10,11]; [IO=2E8h;

IRQ=3,4,5,7,10,11]; [IO=3E0h; IRQ=3,4,5,7,10,11]; [IO=2E0h; IRQ=3,4,5,7,10,11];

**WatchDog Reset Timer**

Use this item to support WDT reset function.

The optional settings: [Disabled]; [Enabled].

When set as [Enabled], the following sub-items shall appear:

**WatchDog Reset Timer Value**

User can set a value in the range of [4] to [255].

**WatchDog Reset Timer Unit**

The optional settings are: [Sec.]; [Min.]

**ATX Power Emulate AT Power**

This item support Emulate AT power function, MB power On/Off control by power supply. Use needs to select 'AT or ATX Mode' on MB jumper at first (refer to JAT\_ATX jumper setting Pin 1&2 of for ATX Mode & Pin 2&3 of AT Mode Select).

**Case Open Detect**

Use this item to detect case has already open or not, show message in POST.

The optional settings: [Disabled]; [Enabled].

When set as [Enabled], system will detect if COPEN has been short or not (*refer to **COPEN** jumper setting for Case Open Detection*); if Pin 1&2 of **COPEN** are short, system will show Case Open Message during POST.

► **PC Health Status**

Press [Enter] to view current hardware health status, make further settings in 'SmartFAN Configuration' and set value in 'Shutdown Temperature'.

► **SmartFAN Configuration**

---

Press [Enter] to make settings for SmartFAN Configuration:

**SmartFAN Configuration**

**CPUFAN/SYSFAN Smart Mode**

The optional settings: [Disabled]; [Enabled].

When set as **[Enabled]**, the following sub-items shall appear:

**CPUFAN/SYSFAN Full-Speed Temperature**

Use this item to set CPUFAN/SYSFAN full speed temperature. Fan will run at full speed when above this pre-set temperature.

**CPUFAN/SYSFAN Full-Speed Duty**

Use this item to set CPUFAN/SYSFAN full-speed duty. Fan will run at full speed when above this pre-set duty.

**CPUFAN/SYSFAN Idle-Speed Temperature**

Use this item to set CPUFAN /SYSFAN idle speed temperature. Fan will run at idle speed when below this pre-set temperature.

**CPUFAN/SYSFAN Idle-Speed Duty**

Use this item to set CPUFAN/SYSFAN idle speed duty. Fan will run at idle speed when below this pre-set duty.

► **Serial Port Console Redirection**

Press [Enter] to make settings for the following sub-items:

**COM1**

**Console Redirection**

Use this item to Console Redirection enable or disable.

The optional settings: [Disabled]; [Enabled].

When set as **[Enabled]**, user can make further settings in the '**Console Redirection Settings**' screen:

► **Console Redirection Settings**

The settings specify how the host computer and the remote computer (which the user is using) will exchange data. Both computers should have the same or compatible settings.

Press [Enter] to make settings for the following sub-items:

**Terminal Type**

---

The optional settings: [VT100]; [VT100Plus]; [VT-UTF8]; [ANSI].

**[ANSI]:** Extended ASCII char set;

**[VT100]:** ASCII char set;

**[VT100Plus]:** Extends VT100 to support color, function keys, etc.;

**[VT-UTF8]:** Uses UTF8 encoding to map Unicode chars onto 1 or more bytes.

### **Bits per second**

Use this item to select serial port transmission speed. The speed must be matched on the other side. Long or noisy lines may require lower speeds.

The optional settings: [9600]; [19200]; [38400]; [57600]; [115200].

### **Data Bits**

The optional settings: [7]; [8].

### **Parity**

A parity bit can be sent with the data bits to detect some transmission errors.

The optional settings: [None]; [Even]; [Odd]; [Mark]; [Space].

**[Even]:** parity bit is 0 if the num of 1's in the data bits is even;

**[Odd]:** parity bit is 0 if num of 1's in the data bits is odd;

**[Mark]:** parity bit is always 1;

**[Space]:** parity bit is always 0;

**[Mark]** and **[Space]:** parity do not allow for error detection.

### **Stop Bits**

Stop bits indicate the end of a serial data packet. (A start bit indicates the beginning). The standard setting is 1 stop bit. Communication with slow devices may require more than 1 stop bit.

The optional settings: [1]; [2].

### **Flow Control**

Flow control can prevent data loss from buffer overflow. When sending data, if the receiving buffers are full, a "stop" signal can be sent to stop the data flow. Once the buffers are empty, a "start" signal can be sent to re-start the flow. Hardware flow control uses two wires to send start/stop signals.

The optional settings: [None]; [Hardware RTS/CTS].

### **VT-UTF8 Combo Key Support**

Use this item to enable VT-UTF8 Combination Key Support for ANSI/VT100 terminals.



---

The optional settings: [Disabled]; [Enabled].

### **Recorder Mode**

With this mode enable only text will be sent. This is to capture Terminal data.

The optional settings: [Disabled]; [Enabled].

### **Resolution 100x31**

Use this item to enable or disable extended terminal resolution.

The optional settings: [Disabled]; [Enabled].

### **Putty KeyPad**

Use this item to select Function Key and KeyPad on Putty.

The optional settings: [VT100]; [LINUX]; [XTERMR6]; [SCO]; [ESCN]; [VT400].

## ► **Legacy Console Redirection Settings**

Press [Enter] to make settings for the following items:

### **Redirection COM Port**

Use this item to select a COM port to display redirection of Legacy OS and Legacy OPRM Messages

The optional settings: [COM1]

### **Resolution**

Use this item to on legacy OS, the number of rows and columns supported redirection

The optional settings: [80x24]; [80x25]

### **Redirect After POST**

When bootloader is selected, then legacy console redirection is disabled before booting to legacy OS. When always enable is selected, the legacy console redirection is enabled for legacy OS. Default setting for this option is set to always enable.

The optional settings: [Always Enable]; [BootLoader]

### **Serial Port for Out-of-Band Management/**

### **Windows Emergency Management Services (EMS)**

### **Console Redirection EMS**

The optional settings: [Disabled]; [Enabled].

When set as **[Enabled]**, user can make further settings in 'Console Redirection Settings' screen:

---

► **Console Redirection Settings**

The settings specify how the host computer and the remote computer (which the user is using) will exchange data. Both computers should have the same or compatible settings.

Press [Enter] to make settings for the following sub-items.

**Terminal Type EMS**

The optional settings: [VT100]; [VT100Plus]; [VT-UTF8]; [ANSI].

**[VT-UTF8]** is the preferred terminal type for out-of-band management. The next best choice is **[VT100+]** and then **[VT100]**. See above, in Console Redirection Settings page, for more help with Terminal Type/Emulation.

**Bits per second EMS**

Use this item to select serial port transmission speed. The speed must be matched on the other side. Long or noisy lines may require lower speeds.

The optional settings: [9600]; [19200]; [57600]; [115200].

**Flow Control**

Flow control can prevent data loss from buffer overflow. When sending data, if the receiving buffers are full, a “stop” signal can be sent to stop the data flow. Once the buffers are empty, a “start” signal can be sent to re-start the flow. Hardware flow control uses two wires to send start/stop signals.

The optional settings: [None]; [Hardware RTS/CTS]; [Software Xon/Xoff].

**Data Bits EMS**

The default setting is: [8].

*\*This item may or may not show up, depending on different configuration.*

**Parity EMS**

The default setting is: [None].

*\*This item may or may not show up, depending on different configuration.*

**Stop Bits EMS**

The default setting is: [1].

*\*This item may or may not show up, depending on different configuration.*

► **USB Configuration**

Press [Enter] to make settings for the following sub-items:

**USB Configuration**

**XHCI Hand-off**

---

This is a workaround for OSeS without XHCI hand-off support. The XHCI ownership change should be claimed by XHCI driver.

The optional settings: [Enabled]; [Disabled].

### **USB Mass Storage Driver Support**

Use this item to enable or disable USB Mass storage driver support

The optional settings: [Disabled]; [Enabled].

### **Port 60/64 Emulation**

Use this item to enables I/O port 60h/64h emulation support. This should be enabled for the complete USB keyboard legacy support for non-USB aware OSeS

The optional settings: [Disabled]; [Enabled].

### **USB hardware delay and time-out**

#### **USB Transfer time-out**

Use this item to set the time-out value for control, bulk, and interrupt transfers.

The optional settings: [1 sec]; [5 sec]; [10 sec]; [20 sec].

#### **Device reset time-out**

Use this item to set USB mass storage device start unit command time-out.

The optional settings: [10 sec]; [20 sec]; [30 sec]; [40 sec].

#### **Device power-up delay**

Use this item to set maximum time the device will take before it properly reports itself to the host controller. 'Auto' uses default value: for a root port it is 100 ms, for a hub port the delay is taken from hub descriptor.

The optional settings: [Auto]; [Manual].

Select **[Manual]** you can set value for the following sub-item: '**Device power-up delay in seconds**', the delay range in from 1 to 40 seconds, in one second increments.

### ► **Network Stack Configuration**

Press [Enter] to go to '**Network Stack**' screen to make further settings.

#### **Network Stack**

Use this item to enable or disable UEFI Network Stack.

The optional settings: [Disabled]; [Enabled].

When set as **[Enabled]**, the following sub-items shall appear:

#### **IPv4 PXE Support**

Use this item to enable IPv4 PXE Boot Support. When set as [Disabled], IPv4 PXE

---

boot option will not be created.

The optional settings: [Disabled]; [Enabled].

### **IPv6 PXE Support**

Use this item to enable IPv6 PXE Boot Support. When set as [Disabled], IPv6 PXE boot option will not be created.

The optional settings: [Disabled]; [Enabled].

### **PXE boot wait time**

Use this item to set wait time to press [ESC] key to abort the PXE boot.

### **Media detect count**

Use this item to set number of times presence of media will be checked.

### ▶ **NVMe Configuration**

Use this item to NVMe Device options settings

### ▶ **Intel(R) Ethernet Controller(3) I225-LM - XX:XX:XX:XX:XX:XX**

This item shows current network brief information.

### ▶ **Intel(R) Ethernet Controller(3) I225-V - XX:XX:XX:XX:XX:XX**

This item shows current network brief information.

### ▶ **Intel(R) Ethernet Controller(3) I225-V - XX:XX:XX:XX:XX:XX**

This item shows current network brief information.

### ▶ **Intel(R) Ethernet Controller(3) I225-V - XX:XX:XX:XX:XX:XX**

This item shows current network brief information.

### ▶ **Intel(R) Ethernet Controller(3) I225-V - XX:XX:XX:XX:XX:XX**

This item shows current network brief information.

### ▶ **Intel(R) Ethernet Controller(3) I225-V - XX:XX:XX:XX:XX:XX**

This item shows current network brief information.

### ▶ **Intel(R) Ethernet Controller(3) I225-V - XX:XX:XX:XX:XX:XX**


This item shows current network brief information.

### ▶ **Intel(R) Ethernet Controller(3) I225-V - XX:XX:XX:XX:XX:XX**

This item shows current network brief information.

---

## 3-8 Chipset Menu



- ▶ **System Agent (SA) Configuration**

Press [Enter] to make settings for the following sub-items:

- ▶ **Memory Configuration**

- ▶ **Maximum Memory Frequency**

Use this item to maximum memory frequency selections in Mhz

The optional settings are: [Auto]; [4000]; [4400]; [4800].

- ▶ **Graphics Configuration**

Press [Enter] to make settings for the following sub-items:

- ▶ **Internal Graphics**

Use this item to keep IGFX enabled based on the setup options.

The optional settings: [Auto]; [Disabled]; [Enabled]

- ▶ **Aperture Size**

Use this item to select the aperture size

Note: Above 4GB MMIO BIOS assignment is automatically enabled when selecting 2048MB aperture. To use this feature, please disable CSM Support.

---

The optional settings: [128MB]; [256MB]; [512MB]; [1024MB]

**DVMT Pre-Allocated**

Use this item to select DVMT 5.0 Pre-Allocated (Fixed) graphics memory size used by the internal graphics device

The optional settings: [32M]; [64M]; [128M]

**DVMT Total Gfx Mem**

Use this item to select DVMT 5.0 total graphic memory size used by the internal graphics device

The optional settings: [128M]; [256M]; [Max]

► **VMD setup menu**

Press [Enter] to make settings for the following sub-items:

**Enable VMD controller**

Use this item to enable/disable to VMD controller

The optional settings: [Disabled]; [Enabled].

When set as [Enabled], the following sub-items shall appear:

**Enable VMD Global Mapping**

Use this item to enable/disable to VMD global mapping

The optional settings: [Disabled]; [Enabled].

When set as [Disabled], the following sub-items shall appear:

**Map this Root Port under VMD**

Use this item to Map/UnMap this root port to VMD

The optional settings: [Disabled]; [Enabled].

**Root Port BDF details**

► **PCH-IO Configuration**

Press [Enter] to make settings for the following sub-items:

**HD Audio**

Use this item to control detection of the HD-Audio device.

Disabled= HAD will be unconditionally disabled

Enabled= HAD will be unconditionally enabled

The optional settings: [Disabled]; [Enabled].

**Onboard Lan1 Controller**

Use this item to enable or disable onboard NIC.

The optional settings: [Enabled]; [Disabled].

---

**Onboard Lan2 Controller**

Use this item to control the PCI Express root port..

The optional settings: [Disabled]; [Enabled].

**Onboard Lan3 Controller**

Use this item to control the PCI Express root port..

The optional settings: [Disabled]; [Enabled].

**Onboard Lan4 Controller**

Use this item to control the PCI Express root port..

The optional settings: [Disabled]; [Enabled].

**Onboard Lan5 Controller**

Use this item to control the PCI Express root port..

The optional settings: [Disabled]; [Enabled].

**Onboard Lan6 Controller**

Use this item to control the PCI Express root port..

The optional settings: [Disabled]; [Enabled].

**Onboard Lan7 Controller**

Use this item to control the PCI Express root port..

The optional settings: [Disabled]; [Enabled].

**Onboard Lan8 Controller**

Use this item to control the PCI Express root port..

The optional settings: [Disabled]; [Enabled].


**System State after Power Failure**

Use this item to specify what state to go to when power re-applied after a power failure (G3 state).

The optional settings: [Always Off]; [Always On]; [Former State].

---

## 3-9 Security Menu



Security menu allow users to change administrator password and user password settings.

### Administrator Password

If there is no password present on system, please press [Enter] to create new administrator password. If password is present on system, please press [Enter] to verify old password then to clear/change password. Press again to confirm the new administrator password.

### User Password

If there is no password present on system, please press [Enter] to create new user password. If password is present on system, please press [Enter] to verify old password then to clear/change password. Press again to confirm the new user password.

#### ► Secure Boot

Press [Enter] to make customized secure settings:

#### System Mode

#### Secure Boot



---

Secure Boot feature is Active if Secure Boot is Enabled, Platform Key(PK) is enrolled and the System is in User mode. The mode change requires platform reset.

The optional settings: [Disabled]; [Enabled].

### **Secure Boot Mode**

Set UEFI Secure Boot Mode to Standard mode or Custom mode. This change is effective after save. After reset, this mode will return to Standard mode.

In Custom mode, Secure Boot Policy variables can be configured by a physically present user without full authentication.

The optional settings: [Standard]; [Custom].

When set as [**Custom**], user can make further settings in the following items that show up:

- ▶ **Restore Factory Keys**

Use this item to force system to User Mode, to install factory default Secure Boot key databases.

- ▶ **Reset To Setup Mode**

Use this item to delete all Secure Boot key databases from NVRAM.

- ▶ **Key Management**

This item enables expert users to modify Secure Boot Policy variables without full authentication, which includes the following items:

### **Vendor Keys**

#### **Factory Key Provision**

This item is for user to install factory default Secure Boot keys after the platform reset and while the System is in Setup mode.

The optional settings: [Disabled]; [Enabled].

- ▶ **Restore Factory Keys**

Use this item to force system into User Mode. Install factory default Secure Boot key databases.

- ▶ **Reset To Setup Mode**

Use this item to delete all Secure Boot key databases from NVRAM.

- ▶ **Enroll Efi Image**

This item allows the image to run in Secure Boot mode.

Enroll SHA256 Hash certificate of a PE image into Authorized Signature Database (db).

---

‣ **Export Secure Boot variables**

Use this item to copy NVRAM content of Secure Boot variables to files in a root folder on a file system device.

**Secure Boot variable/Size/Keys/Key Source**

‣ **Platform Key(PK)/Key Exchange Keys/Authorized Signatures/Forbidden Signatures/ Authorized TimeStamps/OsRecovery Signatures**

Use this item to enroll Factory Defaults or load certificates from a file:

1. Public Key Certificate:


- a) EFI\_SIGNATURE\_LIST
- b) EFI\_CERT\_X509 (DER)
- c) EFI\_CERT\_RSA2048 (bin)
- d) EFI\_CERT\_SHAXXX

2. Authenticated UEFI Variable

3. EFI PE/COFF Image (SHA256)

Key Source: Factory, External, Mixed

## 3-10 Boot Menu



### Boot Configuration

#### ▶ Setup Prompt Timeout

Use this item to set number of seconds to wait for setup activation key.  
65535(0Xffff) means indefinite waiting

#### ▶ Bootup Numlock State

Use this item to select keyboard numlock state.  
The optional settings are: [On]; [Off].

#### ▶ Quiet Boot


The optional settings are: [Disabled]; [Enabled].

When set as [Enabled], user can make settings in the following items that appear:

### Boot Option Priorities

---

## 3-11 Save & Exit Menu




- ▶ **Save Changes and Reset**  
This item allows user to reset the system after saving the changes.
- ▶ **Discard Changes and Reset**  
This item allows user to reset the system without saving any changes.
- ▶ **Restore Defaults**  
Use this item to restore /load default values for all the setup options.
- ▶ **Save as User Defaults**  
Use this item to save the changes done so far as user defaults.
- ▶ **Restore User Defaults**  
Use this item to restore defaults to all the setup options.

### **Boot Override**

---

## 3-12 MEBx



### ► Intel(R) ME Password

Use this item to MEBx Login.