B382FMTU1
User's Manual

Revision: 3.0
Release Date: October 8, 2025

Trademark:

*** Specifications and Information contained in this documentation are furnished for information use only, and are subject to change at any time without notice, and should not be construed as a commitment by manufacturer.**

TABLE OF CONTENT

Environmental Protection and Safety Announcement 4

China RoHS Requirements (EN) 5

User's Notice 6

Manual Revision Information 6

Packing List 6

Chapter 1 Introduction of the Motherboard 7

1-1 Specifications 7

Ordering Information 8

1-2 Block Diagram 9

1-3 Dimension 10

1-4 I/O Placement 11

1-5 Motherboard Placement 12

1-6 Jumper Positions 13

Chapter 2 Hardware Information 14

2-1 List of Jumpers 14

2-2 Jumper Settings 15

2-3 List of Connectors 20

2-4 Connector Settings 21

2-5 Maximum Voltage & Current Limit 31

Chapter 3 Quick Installation Manual 32

3-1 Safety Instructions 32

3-2 Dissemble the Chassis 34

3-3 To Install SO-DIMM to the board 36

3-4 To Install M.2 M-Key (2280) PCIe Card 37

3-5 To Install M.2 E-Key (2230) USB 2.0/PCIe Card 39

3-6 To Install M.2 B-Key (3042/3052) USB 3.2/PCIe Card 43

3-7 To Wall Mount the system 45

Chapter 4 Introducing BIOS 46

4-1 Entering Setup 46

4-2 BIOS Menu Screen 47
4-3 Function Keys 47
4-4 Getting Help 48
4-5 Menu Bars 48
4-6 Main Menu 49
4-7 Advanced Menu 50
4-8 Chipset Menu 62
4-9 Security Menu 65
4-10 Boot Menu 67
4-11 Save & Exit Menu 68
4-12 MEBx 69
Appendix A 70
Appendix B 71

Environmental Protection and Safety Announcement

- Do not dispose this electronic device into the trash while discarding. To minimize pollution and ensure environment protection of mother earth, please recycle.

- Avoid the dusty, humidity and temperature extremes. Do not place the product in any area where it may become wet.

- Generally speaking, dramatic changes in temperature may lead to contact malfunction and crackles due to constant thermal expansion and contraction from the welding spots' that connect components and PCB. Computer should go through an adaptive phase before it boots when it is moved from a cold environment to a warmer one to avoid condensation phenomenon. These water drops attached on PCB or the surface of the components can bring about phenomena as minor as computer instability resulted from corrosion and oxidation from components and PCB or as major as short circuit that can burn the components. Suggest starting the computer until the temperature goes up.

- The increasing temperature of the capacitor may decrease the life of computer. Using the close case may decrease the life of other device because the higher temperature in the inner of the case.

China RoHS Requirements (EN)

Poisonous or Hazardous Substances or Elements in Products

Main Board/ Daughter Board/ Backplane

Name and content of hazardous substances in productPart Name						
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯(PBB)	多溴二苯醚(PBDE)
PCB Assemblies	X	○	○	○	○	○
Connector and Cable	X	○	○	○	○	○
Chassis	○	○	○	○	○	○
Hard Disk	X	○	○	○	○	○
CPU and Memory	X	○	○	○	○	○
Power	X	○	○	○	○	○
Battery	X	○	○	○	○	○

The table is prepared in accordance with the provisions of SJ/T 11364.

○：Indicates that said hazardous substance contained in all of the homogenous materials for this product is below the limit requirement of GB/T 26572.

×：Indicates that said hazardous substance contained in at least one of the homogenous materials used for this part is above the limit requirement of GB/T 26572.

But this product still be compliance with 2011/65/EU Directive (allowed with 2011/65/EU Annex III of RoHS exemption with number 6(c),7(a),7(c)-1)

Notes：

1. This product defined period of use is under normal condition.
2. In above part, CPU/Memory/ Hard Disk/ Power are optional.

User's Notice

COPYRIGHT OF THIS MANUAL BELONGS TO THE MANUFACTURER. NO PART OF THIS MANUAL, INCLUDING THE PRODUCTS AND SOFTWARE DESCRIBED IN IT MAY BE REPRODUCED, TRANSMITTED OR TRANSLATED INTO ANY LANGUAGE IN ANY FORM OR BY ANY MEANS WITHOUT WRITTEN PERMISSION OF THE MANUFACTURER.

THIS MANUAL CONTAINS ALL INFORMATION REQUIRED TO USE THIS MOTHER-BOARD SERIES AND WE DO ASSURE THIS MANUAL MEETS USER'S REQUIREMENT BUT WILL CHANGE, CORRECT ANY TIME WITHOUT NOTICE. MANUFACTURER PROVIDES THIS MANUAL "AS IS" WITHOUT WARRANTY OF ANY KIND, AND WILL NOT BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTIAL OR CONSEQUENTIAL DAMAGES (INCLUDING DAMANGES FOR LOSS OF PROFIT, LOSS OF BUSINESS, LOSS OF USE OF DATA, INTERRUPTION OF BUSINESS AND THE LIKE).

PRODUCTS AND CORPORATE NAMES APPEARING IN THIS MANUAL MAY OR MAY NOT BE REGISTERED TRADEMARKS OR COPYRIGHTS OF THEIR RESPECTIVE COMPANIES, AND THEY ARE USED ONLY FOR IDENTIFICATION OR EXPLANATION AND TO THE OWNER'S BENEFIT, WITHOUT INTENT TO INFRINGE.

Manual Revision Information

Reversion	Revision History	Date
3.0	Third Edition	October 8, 2025

Packing List

Part Number	Description	QTY per System
B382FMTU1	B382FMTU1 Barebone	1
HCS370MWM01B-2-F	Wallmount Kit	2
HCS3XXDINRAILPS-F	Brackets DIN RAIL KITS	2
L01AS066-F	Adapter 19V/4.74A 90W	1
LCSCHBJC3XX-F	Screw Pack	1
Change according to shipping area	Power Cord (Region Specific)	1

Chapter 1 Introduction of the Motherboard

1-1 Specifications


SYSTEM	
MB FORM FACTOR	3.5”
CPU	Onboard Intel® Core™ Ultra 5 Processor 125U (Formerly Meteor Lake, TDP 15W) Onboard Intel® Core™ Ultra 7 Processor 155U (Formerly Meteor Lake, TDP 15W)
CHIPSET	Intel® SoC
MEMORY	2 x DDR5 5600MTs, Dual Channel SO-DIMM, up to 96GB
BIOS	UEFI
WAKE ON LAN	Yes
WATCHDOG TIMER	255 Levels
SECURITY	TPM2.0 (dTPM, Optional)
RTC BATTERY	Lithium Battery
OS SUPPORT	Windows® 11 (64bit) Windows® 10 (64bit) Linux
POWER	
POWER REQUIREMENT	DC-in 12~36V 90W Adapter: AC90~240V, DC19V/4.7A
POWER ON MODE	AT / ATX (Default) Mode
DISPLAY	
GPU	Intel® Graphics
Type-C DP	1 x Type-C DP1.4 (Max Resolution: 4096 x 2160@60Hz)
DP	1 x DP1.4 (Max Resolution: 4096 x 2160@60Hz)
HDMI	1 x HDMI 2.0b (Max Resolution: 4096 x 2160@60Hz)
MULTIPLE DISPLAY	Support 3 Displays
AUDIO	
CODEC	Realtek Audio Codec
AMPLIFIER	3W
LAN	
ETHERNET	1 x RJ45 for Intel® I226-V 2.5GbE 1 x RJ45 for Intel® I226-LM 2.5GbE
SYSTEM I/O	
REAR PANEL I/O	4 x Antenna Holes

	1 x DC-in 1 x HDMI 2.0b 1 x DP 3 x USB 3.2 Gen 2 1 x USB 3.2 Gen 1 Type-C 2 x RJ45 1 x GND Hold
FRONT PANEL I/O	1 x Power Button 1 x Reset Button 1 x Power LED 1 x HDD LED 4 x USB 2.0 4 x RS-232/422/485 4 x Antenna Holes
STORAGE	
SATA	SATA Storage Available Upon Request
EXPANSION	
M.2	1 x E-Key 2230 (USB 2.0/PCIe 3.0 x1) Support CNVi 1 x B-Key 3042/3052 (USB 3.2/PCIe 3.0 x2) 1 x M-Key 2242/2280 (PCIe 4.0 x4 / SATA III) Support NVMe
SIM	1 x Nano SIM Card Slot
MECHANICAL	
MOUNTING	Desktop, Wallmount, Din Rail
DIMENSIONS (W x H x D)	185.0 (W) x 142.0 (D) x 61.0 (H) mm (7.28" x 5.6" x 2.4")
NET WEIGHT	3.5 kg
ENVIRONMENT & CERTIFICATION	
OPERATING TEMPERATURE	-20°C ~ 60°C (-4°F ~ 140°F)
STORAGE TEMPERATURE	-20°C ~ 85°C (-4°F ~ 185°F)
OPERATING HUMIDITY	10 ~ 90% relative humidity, non-condensing
CERTIFICATION	CE/FCC Class A LVD


Ordering Information

PART NUMBER	B382FMTU1-A111	B382FMTU1-A211	B382FMTU1-A311	B382FMTU1-A411
CPU	Intel® Core™ Ultra 5 125U	Intel® Core™ Ultra 5 125U	Intel® Core™ Ultra 7 155U	Intel® Core™ Ultra 7 155U
SECURITY	Intel® PTT (fTPM)	TPM2.0	Intel® PTT (fTPM)	TPM2.0

1-2 Block Diagram




1-3 Dimension




1-4 I/O Placement


Front I/O




Rear I/O



1-5 Motherboard Placement



1-6 Jumper Positions



Chapter 2 Hardware Information


2-1 List of Jumpers


Please refer to the table below for all of the board's jumpers that you can configure for your application.

Location Printing	Function
JPAT1	ATX Mode/AT Mode Select
JPM2B1	M.2 B-key Power Select
JPM2E1	M.2 E-key Power Select
JPCOM1	COM1 Port Pin-9 Function Select
JPCOM2	COM3 Port Pin-9 Function Select
JCLR1 (1-2 pin)	Clear CMOS Function Select
JCLR1 (3-4 pin)	Clear RTC Function Select
JCLR1 (5-6 pin)	ME Disable Function Select
JCLR1 (7-8 pin)	CASE OPEN Message Display Function
JCLR1 (9-10 pin)	SET GPIO Function Select


2-2 Jumper Settings

(1) ATX Mode/AT Mode Select (JPAT1)







1-2 Closed: ATX Mode Selected;



2-3 Closed: AT Mode Selected.

(2) M.2 B-key Power Select (JPM2B1)






1-2 Closed: VCC=3.3V;



2-3 Closed: VCC=3VSB.

(3) M.2 E-key Power Select (JPM2E1)







1-2 Closed: VCC=3.3V;




2-3 Closed: VCC=3VSB.

(4) COM1 Port Pin-9 Function Select (JPCOM1)






2-4 Closed:
RI=RS232;





3-4 Closed:
RI=5V;




4-6 Closed:
RI=12V.


(5) COM3 Port Pin-9 Function Select (JPCOM2)







(6) Clear CMOS Function Select (JCLR1 1-2 pin)






(7) Clear RTC Function Select (JCLR1 3-4 pin)







3-4 Open: Normal(Default)




3-4 Closed: Clear RTC

(8) ME Disable Function Select (JCLR1 5-6 pin)







5-6 Open: Normal(Default)




5-6 Closed: ME Disable

(12) CASE OPEN Message Display Function (JCLR1 7-8 pin)







7-8 Open: Normal(Default)




7-8 Closed: CASE OPEN

(13) SET GPIO Function Select (JCLR1 9-10 pin)





9-10 Open: Normal(Default)



9-10 Closed: SET GPIO


2-3 List of Connectors


Please refer to the table below for all of the board's jumpers that you can configure for your application.

Location Printing	Function
BATCON1	RTC Battery Connector
UL1	RJ45 2.5GbE Lan Connector and USB 3.2 Gen2 Connector
UL2	RJ45 2.5GbE Lan Connector and USB 3.2 Gen2 Connector
DCIN1	Internal 12V~36V Wide-Voltage Power Connector
JW_FP1	Front Panel Header
F_USB1	USB2.0 Port Header
F_USB2	USB2.0 Port Header
COM1	RS232/RS422/RS485 Serial Port Header
COM2	RS232/RS422/RS485 Serial Port Header
COM3	RS232/RS422/RS485 Serial Port Header
COM4	RS232/RS422/RS485 Serial Port Header
GPIO1	8 Bit GPIO Port /80 Port Header
USB1	USB 3.2 Gen2 Connector and Type-C Gen2x2 Connector
DP1_HDMI1	Display Port 1.4 Output Connector and HDMI 2.0b Output Connector
SIMCARD1	Nano-SIM Card Socket
M2M1	M.2 2242 KEY M Socket
M2B1	M.2 3042/3052 KEY B Socket
M2E1	M.2 2230 KEY E Socket
SODIMM1	DDR5 SODIMM Socket
SODIMM2	DDR5 SODIMM Socket

2-4 Connector Settings


(1) RTC Battery Connector (BATCON1)





Note: Standard specifications.


(2) RJ45 2.5GbE Lan Connector and USB 3.2 Gen2 Connector (UL1)





Note: Standard specifications.


(3) RJ45 2.5GbE Lan Connector and USB 3.2 Gen2 Connector (UL2)






Note: Standard specifications.


(4) 12V~36V Wide-Voltage Power Connector (DCIN1)







(5) Front Panel Header (JW_FP1)







(6) USB2.0 Port Header (F_USB1)







(7) USB2.0 Port Header (F_USB2)






(8) RS232/RS422/RS485 Serial Port Header (COM1)






Pin NO.	RS232	*RS422	*RS485
Pin 1	DCD	TX-	DATA-
Pin 2	RXD	TX+	DATA+
Pin 3	TXD	RX+	NC
Pin 4	DTR	RX-	NC
Pin 5	GND	GND	GND
Pin 6	DSR	NC	NC
Pin 7	RTS	NC	NC
Pin 8	CTS	NC	NC
Pin 9	RI	NC	NC


(9) RS232/RS422/RS485 Serial Port Header (COM2)






Pin NO.	RS232	*RS422	*RS485
Pin 1	DCD	TX-	DATA-
Pin 2	RXD	TX+	DATA+
Pin 3	TXD	RX+	NC
Pin 4	DTR	RX-	NC
Pin 5	GND	GND	GND
Pin 6	DSR	NC	NC
Pin 7	RTS	NC	NC
Pin 8	CTS	NC	NC
Pin 9	RI	NC	NC


(10) RS232/RS422/RS485 Serial Port Header *(COM3)*






Pin NO.	RS232
Pin 1	DCD
Pin 2	RXD
Pin 3	TXD
Pin 4	DTR
Pin 5	GND
Pin 6	DSR
Pin 7	RTS
Pin 8	CTS
Pin 9	RI


(11) RS232/RS422/RS485 Serial Port Header *(COM4)*







Pin NO.	RS232
Pin 1	DCD
Pin 2	RXD
Pin 3	TXD
Pin 4	DTR
Pin 5	GND
Pin 6	DSR
Pin 7	RTS
Pin 8	CTS
Pin 9	RI

(12) 8 Bit GPIO Port /80 Port Header (GPIO1)






(13) USB 3.2 Gen2 Connector and Type-C Gen2x2 (USB1)






Note: Standard specifications.


(14) Display Port 1.4 Output Connector and HDMI 2.0b Output Connector (DP1_HDMI1)






Note: Standard specifications.


(15) Nano-SIM Card Socket (SIMCARD1)





Note: Standard specifications.


(16) M.2 2242/2280 KEY M Socket (M2M1)





Note: Standard specifications.


(17) M.2 3042/3052 KEY B Socket (M2B1)





Note: Standard specifications.


(18) M.2 2230 KEY E Socket (M2E1)





Note: Standard specifications.


(19) DDR5 SODIMM Socket Up (SODIMM2)






Note: Standard specifications.

(20) DDR5 SODIMM Socket Down (SODIMM1)





Note: Standard specifications.

2-5 Maximum Voltage & Current Limit

Below is a list of maximum voltage & Current Limit specification for motherboard interface (including but not limited to slots, connectors and headers) for setup reference:

Parts		Working Voltage	Current Support
USB PORT FROM	USB1	5V	900mA x1, 3A x1
	UL1	5V	900mA x2
	UL2	5V	900mA x2
	FP_USB1	5V	500mA x2
	FP_USB2	5V	500mA x2
JW_FP1		5V	1A
GPIO1		5V	1A
JPCOM1		5V/12V	500mA
JPCOM2		5V/12V	500mA

Chapter 3 Quick Installation Manual

Notice!	The photos in this file are for illustration purpose only. The model may not be the latest version. Please refer to the product you purchased for actual specification.

3-1 Safety Instructions

1. Read these safety instructions carefully.
2. Retain this user manual for future reference.
3. Disconnect the equipment from all AC outlets before cleaning.
   use only a damp cloth for cleaning. Do not use liquid or spray detergents.
4. For pluggable equipment, the power outlet socket must be located near the
   equipment and easily accessible.
5. Protect the equipment from humidity.
6. Place the equipment on a reliable surface during installation. Dropping or letting
   the equipment fall may cause damage.
7. Ensure that the voltage is correct before connecting the equipment to a power
   outlet.
8. Position the power cord away from high-traffic areas. Do not place anything over
   the power cord.
9. All cautions and warnings on the equipment should be noted.
10. If unused for a long time, disconnect the equipment from the power source to
    avoid damage from transient overvoltage.
11. Never pour liquid into an opening. This may cause fire or electrical shock.
12. Never open the equipment. For safety reasons, the equipment should be
    opened only by qualified service personnel.
13. If one of the following occurs, have the equipment checked by authorized
    service personnel:

●The power cord or plug is damaged.
●Liquid has penetrated the equipment.
●The equipment has been exposed to moisture.
●The equipment is malfunctioning or does not operate according to the user manual.
●The equipment has been dropped and damaged.
●The equipment shows obvious signs of breakage.

16. Any unverified components may cause unexpected damage. To ensure
    Correct installation, always use the components (e.g., screws) provided
    in the accessory box.
17. Batteries are at risk of exploding if incorrectly installed.

Replace only with the same or equivalent type as recommended by the manufacturer.

Discard used batteries according to the manufacturer's instructions.

18. Always disconnect the power cord from the chassis before manually handling the hardware.

Do not implement connections or configuration changes while the device is powered on.

Sudden power surges may damage sensitive electronic components.

19. **CAUTION OF HIGH HEAT FROM TOP COVER!!!**




In working mode, the **B382FMTU1** is capable of operating at an ambient temperature of up to 60 °C. In such cases, the temperature of the top cover may reach a high value. Under such a condition, accidental contact with the **B382FMTU1** needs to be avoided. External surfaces do not need to be touched to operate the equipment. If touching cannot be avoided, please wear protective gloves.

3-2 Disassemble the Chassis




1. Locate the screws at the spots marked on this side of the system and unscrew them one by one.



2. Remove the marked screw on the front IO panel.



3. Remove the marked screw on the rear IO panel.




4. Lift the cover up to open the chassis.




5. The overview of the internal structure of the system with HDD tray pre-installed.

3-3 To Install SO-DIMM to the board




1. Locate the SO-DIMM memory slot on the board.



2. Insert the gold-figure side of the slot on the board compatible SO-DIMM into the slot at 30 degrees and press down. The eject tab will lock it if installed correctly. Press down to secure the SO-DIMM to the slot. The eject tabs will lock automatically if installing direction is correct.


3-4 To Install M.2 M-Key (2242/2280) PCIe Card



1. Locate the M.2 M-Key (2242/2280) slot on the board. Prepare compatible M.2 M-Key (2242/2280) card.



2. To install compatible M.2 M-Key 2280 card, please remove the screw in the marked spot at first. (When using an M.2 M-Key (2242) card, secure the pillar screw at the blue-marked spot)




3. Insert compatible M.2 M-Key (2242/2280) card into the slot. See to it that the golden-finger side should be fully plugged into the slot.



4. Tighten up the screw removed before to the marked spot to secure the card.

Note: *The screw post and nut fixed at location MH4 by default for 8cm type-2280 card installation.*


3-5 To Install M.2 E-Key (2230) USB 2.0/PCIe Card



1. Locate the M.2 E-Key (2230) slot on the board. Prepare compatible M.2 E-Key (2230) card.



2. Remove the marked screw (MH2) and use it to lock compatible card to the slot in later installation.



3. Insert the gold-figure side of the compatible card into the slot and press down. See to it that the golden-finger side should be fully plugged into the slot.



4. Secure the card to the board by tightening up the screw to the marked spot.





5. Locate the reserved antenna holes on the front and rear panels. Remove the dust-proof plugs at the marked locations on the panels to install the antennas.



6. Push this antenna screw head into antenna hole of the rear panel from the backside of the panel.

6-1 **6-2**






The washer ① & the hexagonal screw nut ②. Push the washer ① through the antenna head.



7. And then lock the antenna screw head to the front side of the rear panel with the hexagonal screw nut② and tighten it up.




8. Press the metal hat on the end of the antenna string to corresponding antenna slot on the card as shown.


9. Repeat step 6 to 8, to finish installation of the other antenna.

Notice: *When all necessary installations are finished, please make sure that all cables unplugged before installations are connected to their original locations before restoring the back cover to the chassis and screws on the front panel/back panel/top cover locked to its original locations* ***(Refer to Part I)****. See to it that the cables inside are not blocked or pressed.*


3-6 To Install M.2 B-Key (3042/3052) USB 3.2/PCIe Card




1. Locate the M.2 B-Key (3042/3052) slot on the board. Prepare compatible M.2 M-Key PCIe (3042/3052) card.



2. To install a compatible card, first remove the screw at the red-marked spot. (When using an M.2 B-Key (3042) card, secure the pillar screw at the green-marked spot)



3. Insert compatible M.2 B-Key (3042/3052) card into the slot. See to it that the golden-finger side should be fully plugged into the slot.




4. Tighten up the screw removed before to the marked spot to secure the card.

3-7 To Wall Mount the system



1. Install wall mount rack to the system by tightening two screws in the marked position.Then lock the other two screws on the other side in the same way.



2. Wall mount the system by tightening 4 screws in the marked positions on both sides of the wall racks. See to it that the three smaller screw hole on one installed rack should be parallel to those on the other racks; otherwise please readjust the racks for correct installation.

Chapter 4 Introducing BIOS


Notice!	The BIOS options in this manual are for reference only. Different configurations may lead to difference in BIOS screen and BIOS screens in manuals are usually the first BIOS version when the board is released and may be different from your purchased motherboard. Users are welcome to download the latest BIOS version form our official website.

The BIOS is a program located on a Flash Memory on the motherboard. This program is a bridge between motherboard and operating system. When you start the computer, the BIOS program will gain control. The BIOS first operates an auto-diagnostic test called POST (power on self test) for all the necessary hardware, it detects the entire hardware device and configures the parameters of the hardware synchronization. Only when these tasks are completed done it gives up control of the computer to operating system (OS). Since the BIOS is the only channel for hardware and software to communicate, it is the key factor for system stability, and in ensuring that your system performance as its best.

4-1 Entering Setup

Power on the computer and by pressing <Del> immediately allows you to enter Setup.
If the message disappears before your respond and you still wish to enter Setup, restart the system to try again by turning it OFF then ON or pressing the “RESET” button on the system case. You may also restart by simultaneously pressing <Ctrl>, <Alt> and <Delete> keys. If you do not press the keys at the correct time and the system does not boot, an error message will be displayed and you will again be asked to


Press **<Del>** to enter Setup; press < **F7**> to enter pop-up Boot menu.



BIOS Boot Menu Screen (boot device options please refer to actual configuration)

4-2 BIOS Menu Screen

The following diagram show a general BIOS menu screen:



4-3 Function Keys

In the above BIOS Setup main menu of, you can see several options. We will explain these options step by step in the following pages of this chapter, but let us first see a short description of the function keys you may use here:

- Press ←→ (left, right) to select screen.
- Press ↑↓ (up, down) to choose, in the main menu, the option you want to confirm or to modify.
- Press <Enter> to select.
- Press <+>/<–> keys when you want to modify the BIOS parameters for the active option.
- [F1]: General help.
- [F2]: Previous values.
- [F3]: Optimized defaults.
- [F4]: Save & Exit.
- Press <Esc> to exit from BIOS Setup.

4-4 Getting Help

Main Menu

The on-line description of the highlighted setup function is displayed at the top right corner the screen.

Status Page Setup Menu/Option Page Setup Menu

Press 【F1】 to pop up a small help window that describes the appropriate keys to use and the possible selections for the highlighted item. To exit the Help Window, press **<Esc>.**

4-5 Menu Bars


There are six menu bars on top of BIOS screen:

Main	To change system basic configuration
Advanced	To change system advanced configuration
Chipset	To change chipset configuration
Security	Password settings
Boot	To change boot settings
Save & Exit	Save setting, loading and exit options.

User can press the right or left arrow key on the keyboard to switch from menu bar. The selected one is highlighted.

4-6 Main Menu

Main menu screen includes some basic system information. Highlight the item and then use the <+> or <-> and numerical keyboard keys to select the value you want in each item.




System Date

Set the date. Please use [Tab] to switch between date elements.

System Time

Set the time. Please use [Tab] to switch between time elements.

4-7 Advanced Menu



- **Connectivity Configuration**

  Use this item to configure Connectivity related options. Press [Enter] to make settings for the following sub-items:

  CNVi CRF Present

  CNVi Mode

  This option configures Connectivity.

  CNVi Mode Set the default value to: [Auto Detection]

  The optional settings: [Disabled Integrated]; [Auto Detection].

  [Auto Detection] means that if Discrete solution is discovered it will be enabled by default. Otherwise Integrated solution (CNVi) will be enabled;

  [Disabled Integrated] disables Integrated Solution.

- **CPU Configuration**

  Press [Enter] to view current CPU configuration and make settings for the following sub-items:

- **Efficient-Core Information**

  Use this item to displays the E-Core information.

  Press [Enter] to make settings for the following sub-items:

  L1 Date Cache/L1 Instruction Cache/L2 Cache/L3 Cache

- **Performance-Core Information**

  Use this item to displays the P-Core information.

  Press [Enter] to make settings for the following sub-items:

  L1 Date Cache/L1 Instruction Cache/L2 Cache/L3 Cache

  Boot Performance Mode

  Use this item to select the performance state that the BIOS will set starting from reset vector.

  Boot Performance Mode Set the default value to: [Max Non-Turbo Performance]

  The optional settings: [Min Non-Turbo Performance]; [Max Non-Turbo Performance]; [Turbo Performance].

  Intel(R) SpeedStep(tm)

This item allows more than two frequency ranges to be supported.
Intel(R) SpeedStep(tm) Set the default value to: [Enabled]
The optional settings: [Disabled]; [Enabled].

Turbo Mode

Use this item to enable or disable processor Turbo Mode (requires Intel Speed Step or Intel Speed Shift to be available and enabled).
Turbo Mode Set the default value to: [Enabled]
The optional settings: [Disabled]; [Enabled]; [Customized]

C states

Use this item to enable or disable CPU Power Management. When set as [Enabled], it allows CPU to go to C states when it's not 100% utilized.
C states Set the default value to: [Enabled]
The optional settings: [Disabled]; [Enabled].

Enhanced C-states

Use this item to Enable/Disable C1E. When enabled, CPU will switch to minimum speed when all cores enter C-State.
Enhanced C-states Set the default value to: [Enabled]
The optional settings: [Disabled]; [Enabled].

Package C State Limit

Use this item to maximum package C State Limit setting. CPU default: leaves to factory default value. Auto: initializes to deepest available package C State Limit.
Package C State Limit Set the default value to: [Auto]
The optional settings: [C0/C1]; [C2]; [C3]; [C6]; [C7]; [C7S]; [C8]; [C9]; [C10]; [CPU Default]; [Auto].

- **Power & Performance**

Press [Enter] to make settings for the following sub-items:

- **GT/Media-Power Management Control**

Press [Enter] to make settings for the following sub-items:

RC6(Render Standby)

Use this item to check to enable render standby support.
RC6(Render Standby) Set the default value to: [Enabled]
The optional settings: [Disabled]; [Enabled].

Maximum GT frequency

Use this item to Maximum GT frequency limited by the user. Choose between 200MHZ (RPN) and 1200MHZ (RP0). Value beyond the range will be clipped to min/max supported by SKU.
Maximum GT frequency Set the default value to: [Default Max Frequency]
The optional settings: [Default Max Frequency]; [100Mhz] ; [150Mhz] ; [200Mhz] ; [250Mhz] ; [300Mhz] ; [350Mhz] ; [400Mhz] ; [450Mhz] ; [500Mhz] ; [550Mhz] ; [600Mhz] ; [650Mhz] ; [700Mhz] ; [750Mhz] ; [800Mhz] ; [850Mhz] ; [900Mhz] ; [950Mhz] ; [1000Mhz] ; [1050Mhz] ; [1100Mhz] ; [1150Mhz] ; [1200Mhz].

Disable Turbo GT frequency

Use this item to enabled: disables turbo GT frequency. Disabled: GT frequency is not limited.
Disable Turbo GT frequency Set the default value to: [Disabled]
The optional settings: [Disabled]; [Enabled].

- **PCH-FW Configuration**

Press [Enter] to make settings for the following sub-items:

TPM Device Selection

The optional settings: [dTPM];[PTT]
TPM Device Selection Set the default value to: [PTT]

- **Trusted Computing**

Press [Enter] to make settings in the following sub-items:

Security Device Support

Use this item to enables or disables BIOS support for security device. O.S will not show security device. TCG EFI protocol and INT1A interface will not be available.

The optional settings: [Disabled]; [Enabled].

Security Device Support Set the default value to: [Enabled]

When set as [Enabled], user can make setting in the following items that appear:

SHA256 PCR Bank

Use this item to enable or disable SHA256 PCR Bank.

The optional settings: [Disabled]; [Enabled].

SHA256 PCR Bank Set the default value to: [Enabled]

SHA384 PCR Bank

Use this item to enable or disable SHA384 PCR Bank.

The optional settings: [Disabled]; [Enabled].

SHA384 PCR Bank Set the default value to: [Disabled]

SM3_256 PCR Bank

Use this item to enable or disable SM3_256 PCR Bank.

The optional settings: [Disabled]; [Enabled].

SM3_256 PCR Bank Set the default value to: [Disabled]

Pending Operation

Use this item to schedule an operation for security device.

The optional settings: [None]; [TPM Clear].

Pending Operation Set the default value to: [None]

Note:** **Your computer will reboot during restart in order to change State of Security Device.

- **Wake-up Function Settings**

Wake-up System With Fixed Time

This item will only show when **'Wake-up System with Dynamic Time' is set as [Disabled].*

Use this item to enable or disable system wake-up by RTC alarm. When this function is enabled, system will wake on the time (hr::min::sec) specified.

The optional settings: [Disabled]; [Enabled].

Wake-up System With Fixed Time Set the default value to: [Disabled]

When set as [Enabled], user can make settings in the following items that appear:

Wake-up Hour

Use this item to select 0-23 for example enter 3 for 3am and 15 for 3pm.

Wake-up Hour Set the default value to: [0]

Wake-up Minute

Use this item to select 0-59.

Wake-up Minute Set the default value to: [0]

Wake-up Second

Use this item to select 0-59.

Wake-up Second Set the default value to: [0]

Wake-up System with Dynamic Time

This item will only show when* *'Wake-up System with Fixed Time'*** *is set as [Disabled].*

Use this item to enable or disable system wake-up by RTC alarm. When enabled, system will wake on the current time + Increase minute(s).

Wake-up System with Dynamic Time Set the default value to: [Disabled]

When set as [Enabled], user can make settings in the following items that appear:

Wake-up Minute Increase

Use this item to select 1-60 minute(s).

Wake-up Minute Increase Set the default value to: [1]

PCIE Wake-up from S4-S5

The optional settings: [Disabled]; [Enabled].

PCIE Wake-up from S4-S5 Set the default value to: [Disabled]

USB S4 Wake-up

USB Wake-up is affected by ERP function in S4. Please disable ERP before activating this function in S4.

The optional settings: [Disabled]; [Enabled].

USB S4 Wake-up Set the default value to: [Disabled].

USB S5 Power

The optional settings: [Disabled]; [Enabled].

USB S5 Power Set the default value to: [Enabled].

- **Super IO Configuration**

Press [Enter] to make settings for the following sub-items:

Super IO Configuration

ERP Support

Use this item to make setting for energy-related products function. Disable ERP to active all wake-up function.

The optional settings: [Disabled]; [Enabled].

ERP Support Set the default value to: [Disabled]

- **Serial Port 1 Configuration**

Press [Enter] to make settings for the following items:

Serial Port

Use this item to enable or disable serial port (COM).

The optional settings: [Disabled]; [Enabled].

Serial Port Set the default value to: [Enabled]

When set as [Enabled], user can make settings in the following items that appear:

Change Settings

Use this item to select an optimal settings for super IO device.

The optional settings are: [Auto]; [IO=3F8h; IRQ=4]; [IO=3F8h; IRQ=3,4,5,7,10,11]; [IO=2F8h; IRQ=3,4,5,7,10,11]; [IO=3E8h; IRQ=3,4,5,7,10,11]]; [IO=2E8h; IRQ=3,4,5,7,10,11].

Change Settings Set the default value to: [Auto]

Transmission Mode Select

The optional settings are: [RS422]; [RS232]; [RS485].

Transmission Mode Select Set the default value to: [RS232]

Mode Speed Select

Use this item to RS232/RS422/RS485 Speed Select.

The optional settings are: [RS232/RS422/RS485=250Kbps]; [RS232=1Mbps, RS422/RS485=10Mbps].

Mode Speed Select Set the default value to: [RS232=1Mbps, RS422/RS485=10Mbps]

- **Serial Port 2 Configuration**

Press [Enter] to make settings for the following items:

Serial Port

Use this item to enable or disable serial port (COM).

The optional settings: [Disabled]; [Enabled].

Serial Port Select Set the default value to: [Enabled]

When set as [Enabled], user can make settings in the following items that appear:

Change Settings

Use this item to select an optimal setting for super IO device.

The optional settings are: [Auto]; [IO=2F8h; IRQ=3]; [IO=3F8h; IRQ=3,4,5,7,10,11]; [IO=2F8h; IRQ=3,4,5,7,10,11]; [IO=3E8h; IRQ=3,4,5,7,10,11]]; [IO=2E8h; IRQ=3,4,5,7,10,11].

Change Settings Set the default value to: [Auto]

Transmission Mode Select

The optional settings are: [RS422]; [RS232]; [RS485].

Transmission Mode Select Set the default value to: [RS232]

Mode Speed Select

Use this item to RS232/RS422/RS485 Speed Select.

The optional settings are: [RS232/RS422/RS485=250Kbps]; [RS232=1Mbps, RS422/RS485=10Mbps].

Mode Speed Select Set the default value to: [RS232=1Mbps, RS422/RS485=10Mbps]

- **Serial Port 3 Configuration**

Press [Enter] to make settings for the following items:

Serial Port

Use this item to enable or disable serial port (COM).

The optional settings: [Disabled]; [Enabled].

Serial Port Select Set the default value to: [Enabled]

When set as [Enabled], user can make settings in the following items that appear:

- **Change Settings**

Use this item to select an optimal setting for super IO device.

The optional settings are: [Auto]; [IO=3E8h; IRQ=10]; [IO=3F8h; IRQ=3,4,5,7,10,11]; [IO=2F8h; IRQ=3,4,5,7,10,11]; [IO=3E8h; IRQ=3,4,5,7,10,11] ; [IO=2E8h; IRQ=3,4,5,7,10,11] ; [IO=3E0h; IRQ=3,4,5,7,10,11] ; [IO=2E0h; IRQ=3,4,5,7,10,11].

Change Settings Set the default value to: [Auto]

- **Transmission Mode Select**

The optional settings are: [RS422]; [RS232]; [RS485].

Transmission Mode Select Set the default value to: [RS232]

- **Mode Speed Select**

Use this item to RS232/RS422/RS485 Speed Select.

The optional settings are: [RS232/RS422/RS485=250Kbps]; [RS232=1Mbps, RS422/RS485=10Mbps].

Mode Speed Select Set the default value to: [RS232=1Mbps, RS422/RS485=10Mbps]

- **Serial Port 4 Configuration**

Press [Enter] to make settings for the following items:

Serial Port

Use this item to enable or disable serial port (COM).

The optional settings: [Disabled]; [Enabled].

Serial Port Select Set the default value to: [Enabled]

When set as [Enabled], user can make settings in the following items that appear:

- **Change Settings**

Use this item to select an optimal setting for super IO device.

The optional settings are: [Auto]; [IO=2E8h; IRQ=10]; [IO=3F8h; IRQ=3,4,5,7,10,11]; [IO=2F8h; IRQ=3,4,5,7,10,11]; [IO=3E8h; IRQ=3,4,5,7,10,11] ; [IO=2E8h; IRQ=3,4,5,7,10,11] ; [IO=3E0h; IRQ=3,4,5,7,10,11] ; [IO=2E0h; IRQ=3,4,5,7,10,11].

Change Settings Set the default value to: [Auto]

- **Transmission Mode Select**

The optional settings are: [RS422]; [RS232]; [RS485].

Transmission Mode Select Set the default value to: [RS232]

- **Mode Speed Select**

Use this item to RS232/RS422/RS485 Speed Select.

The optional settings are: [RS232/RS422/RS485=250Kbps]; [RS232=1Mbps, RS422/RS485=10Mbps].

Mode Speed Select Set the default value to: [RS232=1Mbps, RS422/RS485=10Mbps]

WatchDog Reset Timer

Use this item to support WDT reset function.

The optional settings: [Disabled]; [Enabled].

WatchDog Reset Timer Set the default value to: [Disabled]

When set as [Enabled], user can make settings in the following items that appear:

WatchDog Reset Timer Value

User can set a value in the range of [10] to [255] seconds or [1] to [255] minutes.

WatchDog Reset Timer Value Set the default value to: [10]

WatchDog Reset Timer Unit

The optional settings are: [Sec.]; [Min.].

WatchDog Reset Timer Unit Set the default value to: [Sec]

ATX Power Emulate AT Power

This item support Emulate AT power function, MB power On/Off control by power supply. Use needs to select 'AT or ATX Mode' on MB jumper at first (refer to **JPAT1** jumper setting Pin 1&2 of for **ATX Mode** & Pin 2&3 of **AT Mode** Select).

Case Open Detect

Use this item to detect if case have ever been opened. Show message in POST.

The optional settings: [Disabled]; [Enabled].

Case Open Detect Set the default value to: [Disabled]

When set as [Enabled], system will detect if COPEN has been short or not (*refer to* **JCLAR1** *jumper setting for Case Open Detection*); if Pin 7&8 of **JCLAR1** are short, system will show Case Open Message during POST.

- **PC Health Status**

  Press [Enter] to view current hardware health status, make further settings in '**SmartFAN Configuration**'.

- **SmartFAN Configuration**

  Press [Enter] to make settings for SmartFAN Configuration:

SmartFAN Configuration

CPUFAN Smart Mode

The optional settings: [Disabled]; [Enabled].

CPUFAN Smart Mode Set the default value to: [Enabled]

When set as [Enabled], the following sub-items shall appear:

CPUFAN Full-Speed Temperature

Use this item to set CPUFAN full speed temperature. Fan will run at full speed when above this pre-set temperature.

CPUFAN Full-Speed Temperature Set the default value to: [60]

CPUFAN Full-Speed Duty

Use this item to set CPUFAN full-speed duty. Fan will run at full speed when above this pre-set duty.

CPUFAN Full-Speed Duty Set the default value to: [100]

CPUFAN Idle-Speed Temperature

Use this item to set CPUFAN idle speed temperature. Fan will run at idle speed when below this pre-set temperature.

CPUFAN Idle-Speed Temperature Set the default value to: [40]

CPUFAN Idle-Speed Duty

Use this item to set CPUFAN idle speed duty. Fan will run at idle speed when below this pre-set duty.

CPUFAN Idle-Speed Duty Set the default value to: [40]

- **Serial Port Console Redirection**

Press [Enter] to make settings for the following sub-items:

COM1

Console Redirection

Console Redirection enable or disable.

The optional settings: [Disabled]; [Enabled].

Console Redirection Set the default value to: [Disabled]

When set as **[Enabled]**, user can make further settings in the '**Console Redirection Settings**' screen:

- **Console Redirection Settings**

The settings specify how the host computer and the remote computer (which the user is using) will exchange data. Both computers should have the same or compatible settings.

Press [Enter] to make settings for the following sub-items：

Terminal Type

The optional settings: [VT100]; [VT100Plus]; [VT-UTF8]; [ANSI].
[ANSI]: Extended ASCII char set;
[VT100]: ASCII char set;
[VT100Plus]: Extends VT100 to support color, function keys, etc.
[VT-UTF8]: Uses UTF8 encoding to map Unicode chars onto 1 or more bytes.
Terminal Type Set the default value to: [ANSI]

Bits per second

Use this item to select serial port transmission speed. The speed must be matched on the other side. Long or noisy lines may require lower speeds.

The optional settings: [9600]; [19200]; [38400]; [57600]; [115200].

Bits per second Set the default value to: [115200]

Data Bits

The optional settings: [7]; [8].

Data Bits Set the default value to: [8]

Parity

A parity bit can be sent with the data bits to detect some transmission errors.
The optional settings: [None]; [Even]; [Odd]; [Mark]; [Space].
[Even]: parity bit is 0 if the num of 1's in the data bits is even;

[Odd]: parity bit is 0 if num of 1's in the data bits is odd;
[Mark]: parity bit is always 1;
[Space]: parity bit is always 0;
Parity Set the default value to: [None]
[Mark] and **[Space]**: parity do not allow for error detection. They can be used as an additional data bit.

Stop Bits

Stop bits indicate the end of a serial data packet. (A start bit indicates the beginning). The standard setting is 1 stop bit. Communication with slow devices may require more than 1 stop bit.
The optional settings: [1]; [2].
Stop Bits Set the default value to: [1]

Flow Control

Flow control can prevent data loss from buffer overflow. When sending data, if the receiving buffers are full, a "stop" signal can be sent to stop the data flow. Once the buffers are empty, a "start" signal can be sent to re-start the flow. Hardware flow control uses two wires to send start/stop signals.
The optional settings: [None]; [Hardware RTS/CTS].
Flow Control Set the default value to: [None]

VT-UTF8 Combo Key Support

Use this item to enable VT-UTF8 Combination Key Support for ANSI/VT100 terminals.
The optional settings: [Disabled]; [Enabled].
VT-UTF8 Combo Key Support Set the default value to: [Enabled]

Recorder Mode

With this mode enabled only text will be sent. This is to capture Terminal data.
The optional settings: [Disabled]; [Enabled].
Recorder Mode Set the default value to: [Disabled]

Resolution 100x31

Use this item to enable or disable extended terminal resolution.
The optional settings: [Disabled]; [Enabled].
Resolution 100x31 Set the default value to: [Disabled]

Putty KeyPad

Use this item to select FunctionKey and KeyPad on Putty.
The optional settings: [VT100]; [LINUX]; [XTERMR6]; [SCO]; [ESCN]; [VT400].
Putty KeyPad Set the default value to: [VT100]

Serial Port for Out-of-Band Management/

Windows Emergency Management Services (EMS)

Console Redirection EMS

Use this item to enable or disable console redirection.

The optional settings: [Disabled]; [Enabled].

Console Redirection EMS Set the default value to: [Disabled]

When set as **[Enabled]**, user can make further settings in '**Console Redirection Settings**' screen:

- **Console Redirection Settings**

The settings specify how the host computer and the remote computer (which the user is using) will exchange data. Both computers should have the same or compatible settings.

Press [Enter] to make settings for the following sub-items.

Terminal Type EMS

The optional settings: [VT100]; [VT100Plus]; [VT-UTF8]; [ANSI].

[VT-UTF8] is the preferred terminal type for out-of-band management. The next best choice is **[VT100+]** and then **[VT100]**. See above, in Console Redirection Settings page, for more help with Terminal Type/Emulation.

Terminal Type EMS Set the default value to: [VT-UTF8]

Bits per second EMS

Use this item to select serial port transmission speed. The speed must be matched on the other side. Long or noisy lines may require lower speeds.

The optional settings: [9600]; [19200]; [57600]; [115200].

Bits per second EMS Set the default value to: [115200]

Flow Control EMS

Flow control can prevent data loss from buffer overflow. When sending data, if the receiving buffers are full, a “stop” signal can be sent to stop the data flow. Once the buffers are empty, a “start” signal can be sent to re-start the flow. Hardware flow control uses two wires to send start/stop signals.

The optional settings: [None]; [Hardware RTS/CTS]; [Software Xon/Xoff].

Flow Control EMS Set the default value to: [None]

Data Bits EMS

The default setting is: [8].

**This item may or may not show up, depending on different configuration.*

Parity EMS

The default setting is: [None].

**This item may or may not show up, depending on different configuration.*

Stop Bits EMS

The default setting is: [1].

**This item may or may not show up, depending on different configuration.*

- **USB Configuration**

Press [Enter] to make settings for the following sub-items:

USB Configuration

XHCI Hand-off

This is a workaround for OSes without XHCI hand-off support. The XHCI ownership change should be claimed by XHCI driver.

The optional settings: [Enabled]; [Disabled].

XHCI Hand-off Set the default value to: [Disabled].

USB Mass Storage Driver Support

Use this item to enable or disable USB Mass storage driver support.

The optional settings: [Disabled]; [Enabled].

USB Mass Storage Driver Support Set the default value to: [Enabled].

USB hardware delay and time-out

USB Transfer time-out

Use this item to set the time-out value for control, bulk, and interrupt transfers.

The optional settings: [1 sec]; [5 sec]; [10 sec]; [20 sec].

USB Transfer time-out Set the default value to: [20 sec]

Device reset time-out

Use this item to set USB mass storage device start unit command time-out.

The optional settings: [10 sec]; [20 sec]; [30 sec]; [40 sec].

Device reset time-out Set the default value to: [20 sec]

Device power-up delay

Use this item to set maximum time the device will take before it properly reports itself to the host controller. 'Auto' uses default value: for a root port it is 100 ms, for a hub port the delay is taken from hub descriptor.
The optional settings: [Auto]; [Manual].
Device power-up delay Set the default value to: [Auto]
Select **[Manual]** you can set value for the following sub-item: '**Device power-up delay in seconds**', the delay range is 1 .. 40 seconds, in one second increments.

- **Network Stack Configuration**

Press [Enter] to go to '**Network Stack**' screen to make further settings.
Network Stack
Use this item to enable or disable UEFI Network Stack.
The optional settings: [Disabled]; [Enabled].
Network Stack Set the default value to: [Disabled]
When set as **[Enabled]**, the following sub-items shall appear:
IPv4 PXE Support
Use this item to enable/disable IPv4 PXE Boot Support. When set as [Disabled], IPv4 PXE boot support will not be available.
The optional settings: [Disabled]; [Enabled].
IPv4 PXE Support Set the default value to: [Enabled]
IPv6 PXE Support
Use this item to enable/disable IPv6 PXE Boot Support. When set as [Disabled], IPv6 PXE boot support will not be available.
The optional settings: [Disabled]; [Enabled].
IPv6 PXE Support Set the default value to: [Disabled]
PXE boot wait time
Wait time in seconds to press [ESC] key to abort the PXE boot.
Use either [+]/[-] or numeric keys to set the value.
PXE boot wait time Set the default value to: [5]
Media detect count
Use this item to set number of times presence of media will be checked.
Use either [+]/[-] or numeric keys to set the value.
Media detect count Set the default value to: [5]


- **NVMe Configuration**

Use this item to set NVMe Device options settings.

NVMe Configuration

- **Intel (R) Ethernet Controller I226-LM – XX:XX:XX:XX:XX:XX**
- **Intel (R) Ethernet Controller I226-V – XX:XX:XX:XX:XX:XX**

4-8 Chipset Menu



- **System Agent (SA) Configuration**

Press [Enter] to make settings for the following sub-items:

System Agent (SA) Configuration

Maximum Memory Frequency

Maximum Memory Frequency Selections in Mhz.

The optional settings: [Auto]; [4000] ; [4400] ; [4800] ; [5200] ; [5600].

- **Graphics Configuration**

Active LVDS/eDP

Use this item to select the Active LVDS/eDP Configuration.

The optional settings: [Disabled]; [Enabled].

Active LFP Set the default value to: [Disabled]

When set as [Enabled], the following sub-item shall appear:

Panel Type

The optional settings are: [1024x600 1ch 18-bit]; [1024x768 1ch 18-bit]; [1024x768 1ch 24-bit]; [1280x800 1ch 18-bit]; [1280x800 1ch 24-bit]; [1366x768 1ch 18-bit]; [1366x768 1ch 24-bit]; [1440x900 2ch 18-bit]; [1440x900 2ch 24-bit]; [1280x1024 2ch 24-bit]; [1680x1050 2ch 24-bit]; [1920x1080 2ch 24-bit]; [eDP].

Panel Type Set the default value to: [eDP]

Backlight Control

Use this item to make back light control setting.

The optional settings are: [PWM Inverted]; [PWM Normal].

Backlight Control Set the default value to: [PWM Normal]

- **VMD setup menu**

Press [Enter] to make settings for the following sub-items:

Enable VMD controller

Use this item to enable/disable to VMD controller
The optional settings: [Disabled]; [Enabled].
When set as [Enabled], the following sub-items shall appear:

Enable VMD Global Mapping

Use this item to enable/disable to VMD global mapping
The optional settings: [Disabled]; [Enabled].
Enable VMD Global Mapping Set the default value to: [Disabled].

Map SOC SATA Controller under VMD

Use this item to Map/UnMap this root port to VMD
The optional settings: [Disabled]; [Enabled].
Map SOC SATA Controller under VMD Set the default value to: [Disabled].

- **PCH-IO Configuration**

Press [Enter] to make settings for the following sub-items:

PCH-IO Configuration

- **SATA Configuration**

SATA Device Options Settings.

SATA Configuration

SATA Controller(s)

Use this item to enable/disable SATA Device.

The optional settings are: [Enabled]; [Disabled].

SATA Controller(s) Set the default value to: [Enabled]

When set as [Enabled], the following sub-items shall appear:

SATA1

Port

Use this item to enable or disable SATA Port.

The optional settings are: [Disabled]; [Enabled].

Port Set the default value to: [Enabled]

M.2

Port

Use this item to enable or disable SATA Port.

The optional settings are: [Disabled]; [Enabled].

Port Set the default value to: [Enabled]

HD Audio

Use this item to control detection of the HD-Audio device.

Disabled= HDA will be unconditionally disabled.

Enabled= HDA will be unconditionally enabled.

The optional settings: [Disabled]; [Enabled].

HD Audio Set the default value to: [Enabled]

M2B Slot Select

The optional settings: [Auto]; [PCIex2]; [PCIex1+USB3].

M2B Slot Select Set the default value to: [Auto]


System State after Power Failure

Specify what state to go to when power is re-applied after a power failure (G3 state).

The optional settings: [Always On]; [Always Off]; [Former State].

System State after Power Failure Set the default value to: [Always Off]

4-9 Security Menu



Security menu allow users to change administrator password and user password settings.

Administrator Password

If there is no password present on system, please press [Enter] to create new administrator password. If password is present on system, please press [Enter] to verify old password then to clear/change password. Press again to confirm the new administrator password.

User Password

If there is no password present on system, please press [Enter] to create new administrator password. If password is present on system, please press [Enter] to verify old password then to clear/change password. Press again to confirm the new administrator password.

- **Secure Boot**

  Press [Enter] to make customized secure settings:

  System Mode

  Secure Boot

  Secure Boot feature is Active if Secure Boot is Enabled, Platform Key(PK) is enrolled and the System is in User mode. The mode change requires platform reset.

  The optional settings: [Disabled]; [Enabled].

  Secure Boot Set the default value to: [Enabled]

  Secure Boot Mode

  Set UEFI Secure Boot Mode to Standard mode or Custom mode. This change is effective after save. After reset, this mode will return to Standard mode.

  In Custom mode, Secure Boot Policy variables can be configured by a physically present user without full authentication.

  The optional settings: [Standard]; [Custom].

  Secure Boot Mode Set the default value to: [Standard]

  When set as [**Custom**], user can make further settings in the following items that show up:

  - **Restore Factory Keys**

    Use this item to force system to User Mode, to install factory default Secure Boot key databases.

  - **Reset To Setup Mode**

Use this item to Delete all secure boot key databases from NVRAM.

- **Key Management**

This item enables expert users to modify Secure Boot Policy variables without full authentication, which includes the following items:

Vendor Keys

Factory Key Provision

This item is for user to install factory default Secure Boot keys after the platform reset and while the System is in Setup mode.
The optional settings: [Disabled]; [Enabled].
Factory Key Provision Set the default value to: [Disabled]

- **Restore Factory Keys**

Use this item to force system into User Mode. Install factory default Secure Boot key databases.

- **Reset To Setup Mode**

Use this item to Delete all Secure Boot key databases from NVRAM.

- **Enroll Efi Image**

This item allows the image to run in Secure Boot mode.
Enroll SHA256 Hash certificate of a PE image into Authorized Signature Database (db).

- **Export Secure Boot variables**

Use this item to save NVRAM content of Secure Boot variables to a file.


- **Export Secure Boot variables**

- **Platform Key(PK)**
- **Key Exchange Keys(KEK)**
- **Signatures(db)**
- **Forbidden Signatures(dbx)**
- **Authorized TimeStamps(dbt)**
- **OsRecovery Signatures(dbr)**

Use this item to enroll Factory Defaults or load certificates from a file:
1. Public Key Certificate:
   a) EFI_SIGNATURE_LIST
   b) EFI_ CERT_X509 (DER)
   c) EFI_ CERT_RSA2048 (bin)
   d) EFI_ CERT_SHAXXX
2. Authenticated UEFI Variable
3. EFI PE/COFF Image (SHA256)

Key Source: Factory, Modified, Mixed

4-10 Boot Menu



Boot Configuration

Setup Prompt Timeout

Use this item to set number of seconds to wait for setup activation key. 65535 (0xFFFF) means indefinite waiting.

Setup Prompt Timeout Set the default value to: [2]

Bootup NumLock State

Use this item to select keyboard NumLock state.

The optional settings: [On]; [Off].

Bootup NumLock State Set the default value to: [Off]

Quiet Boot


The optional settings: [Disabled]; [Enabled].

Quiet Boot Set the default value to: [Disabled]

Boot Option Priorities

Boot Option #1~#5 This item allows you to set the system boot order. Configuration options: [NVME]; [Hard Disk]; [USB Device]; [Network].

4-11 Save & Exit Menu



Save Changes and Reset

This item allows user to reset the system after saving the changes.

Discard Changes and Reset

This item allows user to reset the system setup without saving any changes.

Restore Defaults

Use this item to restore /load default values for all the setup options.

Save as User Defaults


Use this item to save the changes done so far as user defaults.

Restore User Defaults

Use this item to restore the user defaults to all the setup options.

Boot Override

4-12 MEBx



- **Intel(R) ME Password**

  Use this item to MEBx Login


Appendix A


Mating Connectors

Location Printing	Function	Vendor	Vendor P/N
COM1	RS232 / RS422 / RS485 Serial Port Header (onboard)	Topt (鑫冠輝電子)	PH200-205M-GBB00010D
COM2	RS232 / RS422 / RS485 Serial Port Header (onboard)	Topt (鑫冠輝電子)	PH200-205M-GBB00010D
COM3	RS232 / RS422 / RS485 Serial Port Header (onboard)	Topt (鑫冠輝電子)	PH200-205M-GBB00010D
COM4	RS232 / RS422 / RS485 Serial Port Header (onboard)	Topt (鑫冠輝電子)	PH200-205M-GBB00010D
DCIN3	External 12 ~ 36V Wide-Range input DC Jack connector	SHENG CONG (盛聰電子)	DJ-D020AE
FUSB1 & FUSB2	Front Panel USB 2.0 Type-A connector	ZONY (宗義科技)	A052010018
DP1-HDMI1	DP1.4 Port Connector and HDMI2.0b Port Connector	ZONY (宗義科技)	A132110S1-11
TC1	USB3.2 Gen. 2 Type- C Port Connector	ARGOSY (優群科技)	UCF3T-4TN30-0P0B
USB1	USB3.2 Gen. 2 Port Connector	LOTES	AUSB0174-K004C
UL1 & UL2	RJ45 2.5GbE Lan Connector and USB 3.2 Gen2 Connector	UDE (湧德電子)	RH1-JT-0005


Appendix B


I/O Address Map







Memory Address Map








IRQ Mapping Chart









Device Manager
File Action View Help
(ISA) 0x00000066 (102) Microsoft ACPI-Compliant System
(ISA) 0x00000067 (103) Microsoft ACPI-Compliant System
(ISA) 0x00000068 (104) Microsoft ACPI-Compliant System
(ISA) 0x00000069 (105) Microsoft ACPI-Compliant System
(ISA) 0x0000006A (106) Microsoft ACPI-Compliant System
(ISA) 0x0000006B (107) Microsoft ACPI-Compliant System
(ISA) 0x0000006C (108) Microsoft ACPI-Compliant System
(ISA) 0x0000006D (109) Microsoft ACPI-Compliant System
(ISA) 0x0000006E (110) Microsoft ACPI-Compliant System
(ISA) 0x0000006F (111) Microsoft ACPI-Compliant System
(ISA) 0x00000070 (112) Microsoft ACPI-Compliant System
(ISA) 0x00000071 (113) Microsoft ACPI-Compliant System
(ISA) 0x00000072 (114) Microsoft ACPI-Compliant System
(ISA) 0x00000073 (115) Microsoft ACPI-Compliant System
(ISA) 0x00000074 (116) Microsoft ACPI-Compliant System
(ISA) 0x00000075 (117) Microsoft ACPI-Compliant System
(ISA) 0x00000076 (118) Microsoft ACPI-Compliant System
(ISA) 0x00000077 (119) Microsoft ACPI-Compliant System
(ISA) 0x00000078 (120) Microsoft ACPI-Compliant System
(ISA) 0x00000079 (121) Microsoft ACPI-Compliant System
(ISA) 0x0000007A (122) Microsoft ACPI-Compliant System
(ISA) 0x0000007B (123) Microsoft ACPI-Compliant System
(ISA) 0x0000007C (124) Microsoft ACPI-Compliant System
(ISA) 0x0000007D (125) Microsoft ACPI-Compliant System
(ISA) 0x0000007E (126) Microsoft ACPI-Compliant System
(ISA) 0x0000007F (127) Microsoft ACPI-Compliant System
(ISA) 0x00000080 (128) Microsoft ACPI-Compliant System
(ISA) 0x00000081 (129) Microsoft ACPI-Compliant System
Actions
Device Manager
More Actions



Device Manager
File Action View Help
(ISA) 0x0000009C (156) Microsoft ACPI-Compliant System
(ISA) 0x0000009D (157) Microsoft ACPI-Compliant System
(ISA) 0x0000009E (158) Microsoft ACPI-Compliant System
(ISA) 0x0000009F (159) Microsoft ACPI-Compliant System
(ISA) 0x000000A0 (160) Microsoft ACPI-Compliant System
(ISA) 0x000000A1 (161) Microsoft ACPI-Compliant System
(ISA) 0x000000A2 (162) Microsoft ACPI-Compliant System
(ISA) 0x000000A3 (163) Microsoft ACPI-Compliant System
(ISA) 0x000000A4 (164) Microsoft ACPI-Compliant System
(ISA) 0x000000A5 (165) Microsoft ACPI-Compliant System
(ISA) 0x000000A6 (166) Microsoft ACPI-Compliant System
(ISA) 0x000000A7 (167) Microsoft ACPI-Compliant System
(ISA) 0x000000A8 (168) Microsoft ACPI-Compliant System
(ISA) 0x000000A9 (169) Microsoft ACPI-Compliant System
(ISA) 0x000000AA (170) Microsoft ACPI-Compliant System
(ISA) 0x000000AB (171) Microsoft ACPI-Compliant System
(ISA) 0x000000AC (172) Microsoft ACPI-Compliant System
(ISA) 0x000000AD (173) Microsoft ACPI-Compliant System
(ISA) 0x000000AE (174) Microsoft ACPI-Compliant System
(ISA) 0x000000AF (175) Microsoft ACPI-Compliant System
(ISA) 0x000000B0 (176) Microsoft ACPI-Compliant System
(ISA) 0x000000B1 (177) Microsoft ACPI-Compliant System
(ISA) 0x000000B2 (178) Microsoft ACPI-Compliant System
(ISA) 0x000000B3 (179) Microsoft ACPI-Compliant System
(ISA) 0x000000B4 (180) Microsoft ACPI-Compliant System
(ISA) 0x000000B5 (181) Microsoft ACPI-Compliant System
(ISA) 0x000000B6 (182) Microsoft ACPI-Compliant System
(ISA) 0x000000B7 (183) Microsoft ACPI-Compliant System
Actions
Device Manager
More Actions



Device Manager
File Action View Help
(ISA) 0x00000081 (129) Microsoft ACPI-Compliant System
(ISA) 0x00000082 (130) Microsoft ACPI-Compliant System
(ISA) 0x00000083 (131) Microsoft ACPI-Compliant System
(ISA) 0x00000084 (132) Microsoft ACPI-Compliant System
(ISA) 0x00000085 (133) Microsoft ACPI-Compliant System
(ISA) 0x00000086 (134) Microsoft ACPI-Compliant System
(ISA) 0x00000087 (135) Microsoft ACPI-Compliant System
(ISA) 0x00000088 (136) Microsoft ACPI-Compliant System
(ISA) 0x00000089 (137) Microsoft ACPI-Compliant System
(ISA) 0x0000008A (138) Microsoft ACPI-Compliant System
(ISA) 0x0000008B (139) Microsoft ACPI-Compliant System
(ISA) 0x0000008C (140) Microsoft ACPI-Compliant System
(ISA) 0x0000008D (141) Microsoft ACPI-Compliant System
(ISA) 0x0000008E (142) Microsoft ACPI-Compliant System
(ISA) 0x0000008F (143) Microsoft ACPI-Compliant System
(ISA) 0x00000090 (144) Microsoft ACPI-Compliant System
(ISA) 0x00000091 (145) Microsoft ACPI-Compliant System
(ISA) 0x00000092 (146) Microsoft ACPI-Compliant System
(ISA) 0x00000093 (147) Microsoft ACPI-Compliant System
(ISA) 0x00000094 (148) Microsoft ACPI-Compliant System
(ISA) 0x00000095 (149) Microsoft ACPI-Compliant System
(ISA) 0x00000096 (150) Microsoft ACPI-Compliant System
(ISA) 0x00000097 (151) Microsoft ACPI-Compliant System
(ISA) 0x00000098 (152) Microsoft ACPI-Compliant System
(ISA) 0x00000099 (153) Microsoft ACPI-Compliant System
(ISA) 0x0000009A (154) Microsoft ACPI-Compliant System
(ISA) 0x0000009B (155) Microsoft ACPI-Compliant System
(ISA) 0x0000009C (156) Microsoft ACPI-Compliant System
Actions
Device Manager
More Actions



Device Manager
File Action View Help
(ISA) 0x000000B7 (183) Microsoft ACPI-Compliant System
(ISA) 0x000000B8 (184) Microsoft ACPI-Compliant System
(ISA) 0x000000B9 (185) Microsoft ACPI-Compliant System
(ISA) 0x000000BA (186) Microsoft ACPI-Compliant System
(ISA) 0x000000BB (187) Microsoft ACPI-Compliant System
(ISA) 0x000000BC (188) Microsoft ACPI-Compliant System
(ISA) 0x000000BD (189) Microsoft ACPI-Compliant System
(ISA) 0x000000BE (190) Microsoft ACPI-Compliant System
(ISA) 0x000000BF (191) Microsoft ACPI-Compliant System
(ISA) 0x000000C0 (192) Microsoft ACPI-Compliant System
(ISA) 0x000000C1 (193) Microsoft ACPI-Compliant System
(ISA) 0x000000C2 (194) Microsoft ACPI-Compliant System
(ISA) 0x000000C3 (195) Microsoft ACPI-Compliant System
(ISA) 0x000000C4 (196) Microsoft ACPI-Compliant System
(ISA) 0x000000C5 (197) Microsoft ACPI-Compliant System
(ISA) 0x000000C6 (198) Microsoft ACPI-Compliant System
(ISA) 0x000000C7 (199) Microsoft ACPI-Compliant System
(ISA) 0x000000C8 (200) Microsoft ACPI-Compliant System
(ISA) 0x000000C9 (201) Microsoft ACPI-Compliant System
(ISA) 0x000000CA (202) Microsoft ACPI-Compliant System
(ISA) 0x000000CB (203) Microsoft ACPI-Compliant System
(ISA) 0x000000CC (204) Microsoft ACPI-Compliant System
(ISA) 0x00000100 (256) Microsoft ACPI-Compliant System
(ISA) 0x00000101 (257) Microsoft ACPI-Compliant System
(ISA) 0x00000102 (258) Microsoft ACPI-Compliant System
(ISA) 0x00000103 (259) Microsoft ACPI-Compliant System
(ISA) 0x00000104 (260) Microsoft ACPI-Compliant System
(ISA) 0x00000105 (261) Microsoft ACPI-Compliant System
Actions
Device Manager
More Actions



Device Manager
File Action View Help
(ISA) 0x00000105 (261) Microsoft ACPI-Compliant System
(ISA) 0x00000106 (262) Microsoft ACPI-Compliant System
(ISA) 0x00000107 (263) Microsoft ACPI-Compliant System
(ISA) 0x00000108 (264) Microsoft ACPI-Compliant System
(ISA) 0x00000109 (265) Microsoft ACPI-Compliant System
(ISA) 0x0000010A (266) Microsoft ACPI-Compliant System
(ISA) 0x0000010B (267) Microsoft ACPI-Compliant System
(ISA) 0x0000010C (268) Microsoft ACPI-Compliant System
(ISA) 0x0000010D (269) Microsoft ACPI-Compliant System
(ISA) 0x0000010E (270) Microsoft ACPI-Compliant System
(ISA) 0x0000010F (271) Microsoft ACPI-Compliant System
(ISA) 0x00000110 (272) Microsoft ACPI-Compliant System
(ISA) 0x00000111 (273) Microsoft ACPI-Compliant System
(ISA) 0x00000112 (274) Microsoft ACPI-Compliant System
(ISA) 0x00000113 (275) Microsoft ACPI-Compliant System
(ISA) 0x00000114 (276) Microsoft ACPI-Compliant System
(ISA) 0x00000115 (277) Microsoft ACPI-Compliant System
(ISA) 0x00000116 (278) Microsoft ACPI-Compliant System
(ISA) 0x00000117 (279) Microsoft ACPI-Compliant System
(ISA) 0x00000118 (280) Microsoft ACPI-Compliant System
(ISA) 0x00000119 (281) Microsoft ACPI-Compliant System
(ISA) 0x0000011A (282) Microsoft ACPI-Compliant System
(ISA) 0x0000011B (283) Microsoft ACPI-Compliant System
(ISA) 0x0000011C (284) Microsoft ACPI-Compliant System
(ISA) 0x0000011D (285) Microsoft ACPI-Compliant System
(ISA) 0x0000011E (286) Microsoft ACPI-Compliant System
(ISA) 0x0000011F (287) Microsoft ACPI-Compliant System
(ISA) 0x00000120 (288) Microsoft ACPI-Compliant System
Actions
Device Manager
More Actions



Device Manager
File Action View Help
(ISA) 0x00000120 (288) Microsoft ACPI-Compliant System
(ISA) 0x00000121 (289) Microsoft ACPI-Compliant System
(ISA) 0x00000122 (290) Microsoft ACPI-Compliant System
(ISA) 0x00000123 (291) Microsoft ACPI-Compliant System
(ISA) 0x00000124 (292) Microsoft ACPI-Compliant System
(ISA) 0x00000125 (293) Microsoft ACPI-Compliant System
(ISA) 0x00000126 (294) Microsoft ACPI-Compliant System
(ISA) 0x00000127 (295) Microsoft ACPI-Compliant System
(ISA) 0x00000128 (296) Microsoft ACPI-Compliant System
(ISA) 0x00000129 (297) Microsoft ACPI-Compliant System
(ISA) 0x0000012A (298) Microsoft ACPI-Compliant System
(ISA) 0x0000012B (299) Microsoft ACPI-Compliant System
(ISA) 0x0000012C (300) Microsoft ACPI-Compliant System
(ISA) 0x0000012D (301) Microsoft ACPI-Compliant System
(ISA) 0x0000012E (302) Microsoft ACPI-Compliant System
(ISA) 0x0000012F (303) Microsoft ACPI-Compliant System
(ISA) 0x00000130 (304) Microsoft ACPI-Compliant System
(ISA) 0x00000131 (305) Microsoft ACPI-Compliant System
(ISA) 0x00000132 (306) Microsoft ACPI-Compliant System
(ISA) 0x00000133 (307) Microsoft ACPI-Compliant System
(ISA) 0x00000134 (308) Microsoft ACPI-Compliant System
(ISA) 0x00000135 (309) Microsoft ACPI-Compliant System
(ISA) 0x00000136 (310) Microsoft ACPI-Compliant System
(ISA) 0x00000137 (311) Microsoft ACPI-Compliant System
(ISA) 0x00000138 (312) Microsoft ACPI-Compliant System
(ISA) 0x00000139 (313) Microsoft ACPI-Compliant System
(ISA) 0x0000013A (314) Microsoft ACPI-Compliant System
(ISA) 0x0000013B (315) Microsoft ACPI-Compliant System
Actions
Device Manager
More Actions



Device Manager
File Action View Help
(ISA) 0x0000013B (315) Microsoft ACPI-Compliant System
(ISA) 0x0000013C (316) Microsoft ACPI-Compliant System
(ISA) 0x0000013D (317) Microsoft ACPI-Compliant System
(ISA) 0x0000013E (318) Microsoft ACPI-Compliant System
(ISA) 0x0000013F (319) Microsoft ACPI-Compliant System
(ISA) 0x00000140 (320) Microsoft ACPI-Compliant System
(ISA) 0x00000141 (321) Microsoft ACPI-Compliant System
(ISA) 0x00000142 (322) Microsoft ACPI-Compliant System
(ISA) 0x00000143 (323) Microsoft ACPI-Compliant System
(ISA) 0x00000144 (324) Microsoft ACPI-Compliant System
(ISA) 0x00000145 (325) Microsoft ACPI-Compliant System
(ISA) 0x00000146 (326) Microsoft ACPI-Compliant System
(ISA) 0x00000147 (327) Microsoft ACPI-Compliant System
(ISA) 0x00000148 (328) Microsoft ACPI-Compliant System
(ISA) 0x00000149 (329) Microsoft ACPI-Compliant System
(ISA) 0x0000014A (330) Microsoft ACPI-Compliant System
(ISA) 0x0000014B (331) Microsoft ACPI-Compliant System
(ISA) 0x0000014C (332) Microsoft ACPI-Compliant System
(ISA) 0x0000014D (333) Microsoft ACPI-Compliant System
(ISA) 0x0000014E (334) Microsoft ACPI-Compliant System
(ISA) 0x0000014F (335) Microsoft ACPI-Compliant System
(ISA) 0x00000150 (336) Microsoft ACPI-Compliant System
(ISA) 0x00000151 (337) Microsoft ACPI-Compliant System
(ISA) 0x00000152 (338) Microsoft ACPI-Compliant System
(ISA) 0x00000153 (339) Microsoft ACPI-Compliant System
(ISA) 0x00000154 (340) Microsoft ACPI-Compliant System
(ISA) 0x00000155 (341) Microsoft ACPI-Compliant System
(ISA) 0x00000156 (342) Microsoft ACPI-Compliant System
Actions
Device Manager
More Actions



Device Manager
File Action View Help
(ISA) 0x00000156 (342) Microsoft ACPI-Compliant System
(ISA) 0x00000157 (343) Microsoft ACPI-Compliant System
(ISA) 0x00000158 (344) Microsoft ACPI-Compliant System
(ISA) 0x00000159 (345) Microsoft ACPI-Compliant System
(ISA) 0x0000015A (346) Microsoft ACPI-Compliant System
(ISA) 0x0000015B (347) Microsoft ACPI-Compliant System
(ISA) 0x0000015C (348) Microsoft ACPI-Compliant System
(ISA) 0x0000015D (349) Microsoft ACPI-Compliant System
(ISA) 0x0000015E (350) Microsoft ACPI-Compliant System
(ISA) 0x0000015F (351) Microsoft ACPI-Compliant System
(ISA) 0x00000160 (352) Microsoft ACPI-Compliant System
(ISA) 0x00000161 (353) Microsoft ACPI-Compliant System
(ISA) 0x00000162 (354) Microsoft ACPI-Compliant System
(ISA) 0x00000163 (355) Microsoft ACPI-Compliant System
(ISA) 0x00000164 (356) Microsoft ACPI-Compliant System
(ISA) 0x00000165 (357) Microsoft ACPI-Compliant System
(ISA) 0x00000166 (358) Microsoft ACPI-Compliant System
(ISA) 0x00000167 (359) Microsoft ACPI-Compliant System
(ISA) 0x00000168 (360) Microsoft ACPI-Compliant System
(ISA) 0x00000169 (361) Microsoft ACPI-Compliant System
(ISA) 0x0000016A (362) Microsoft ACPI-Compliant System
(ISA) 0x0000016B (363) Microsoft ACPI-Compliant System
(ISA) 0x0000016C (364) Microsoft ACPI-Compliant System
(ISA) 0x0000016D (365) Microsoft ACPI-Compliant System
(ISA) 0x0000016E (366) Microsoft ACPI-Compliant System
(ISA) 0x0000016F (367) Microsoft ACPI-Compliant System
(ISA) 0x00000170 (368) Microsoft ACPI-Compliant System
(ISA) 0x00000171 (369) Microsoft ACPI-Compliant System
Actions
Device Manager
More Actions



Device Manager
File Action View Help
(ISA) 0x00000171 (369) Microsoft ACPI-Compliant System
(ISA) 0x00000172 (370) Microsoft ACPI-Compliant System
(ISA) 0x00000173 (371) Microsoft ACPI-Compliant System
(ISA) 0x00000174 (372) Microsoft ACPI-Compliant System
(ISA) 0x00000175 (373) Microsoft ACPI-Compliant System
(ISA) 0x00000176 (374) Microsoft ACPI-Compliant System
(ISA) 0x00000177 (375) Microsoft ACPI-Compliant System
(ISA) 0x00000178 (376) Microsoft ACPI-Compliant System
(ISA) 0x00000179 (377) Microsoft ACPI-Compliant System
(ISA) 0x0000017A (378) Microsoft ACPI-Compliant System
(ISA) 0x0000017B (379) Microsoft ACPI-Compliant System
(ISA) 0x0000017C (380) Microsoft ACPI-Compliant System
(ISA) 0x0000017D (381) Microsoft ACPI-Compliant System
(ISA) 0x0000017E (382) Microsoft ACPI-Compliant System
(ISA) 0x0000017F (383) Microsoft ACPI-Compliant System
(ISA) 0x00000180 (384) Microsoft ACPI-Compliant System
(ISA) 0x00000181 (385) Microsoft ACPI-Compliant System
(ISA) 0x00000182 (386) Microsoft ACPI-Compliant System
(ISA) 0x00000183 (387) Microsoft ACPI-Compliant System
(ISA) 0x00000184 (388) Microsoft ACPI-Compliant System
(ISA) 0x00000185 (389) Microsoft ACPI-Compliant System
(ISA) 0x00000186 (390) Microsoft ACPI-Compliant System
(ISA) 0x00000187 (391) Microsoft ACPI-Compliant System
(ISA) 0x00000188 (392) Microsoft ACPI-Compliant System
(ISA) 0x00000189 (393) Microsoft ACPI-Compliant System
(ISA) 0x0000018A (394) Microsoft ACPI-Compliant System
(ISA) 0x0000018B (395) Microsoft ACPI-Compliant System
(ISA) 0x0000018C (396) Microsoft ACPI-Compliant System
Actions
Device Manager
More Actions


Device Manager
File Action View Help
(ISA) 0x0000018C (396) Microsoft ACPI-Compliant System
(ISA) 0x0000018D (397) Microsoft ACPI-Compliant System
(ISA) 0x0000018E (398) Microsoft ACPI-Compliant System
(ISA) 0x0000018F (399) Microsoft ACPI-Compliant System
(ISA) 0x00000190 (400) Microsoft ACPI-Compliant System
(ISA) 0x00000191 (401) Microsoft ACPI-Compliant System
(ISA) 0x00000192 (402) Microsoft ACPI-Compliant System
(ISA) 0x00000193 (403) Microsoft ACPI-Compliant System
(ISA) 0x00000194 (404) Microsoft ACPI-Compliant System
(ISA) 0x00000195 (405) Microsoft ACPI-Compliant System
(ISA) 0x00000196 (406) Microsoft ACPI-Compliant System
(ISA) 0x00000197 (407) Microsoft ACPI-Compliant System
(ISA) 0x00000198 (408) Microsoft ACPI-Compliant System
(ISA) 0x00000199 (409) Microsoft ACPI-Compliant System
(ISA) 0x0000019A (410) Microsoft ACPI-Compliant System
(ISA) 0x0000019B (411) Microsoft ACPI-Compliant System
(ISA) 0x0000019C (412) Microsoft ACPI-Compliant System
(ISA) 0x0000019D (413) Microsoft ACPI-Compliant System
(ISA) 0x0000019E (414) Microsoft ACPI-Compliant System
(ISA) 0x0000019F (415) Microsoft ACPI-Compliant System
(ISA) 0x000001A0 (416) Microsoft ACPI-Compliant System
(ISA) 0x000001A1 (417) Microsoft ACPI-Compliant System
(ISA) 0x000001A2 (418) Microsoft ACPI-Compliant System
(ISA) 0x000001A3 (419) Microsoft ACPI-Compliant System
(ISA) 0x000001A4 (420) Microsoft ACPI-Compliant System
(ISA) 0x000001A5 (421) Microsoft ACPI-Compliant System
(ISA) 0x000001A6 (422) Microsoft ACPI-Compliant System
(ISA) 0x000001A7 (423) Microsoft ACPI-Compliant System
Actions
Device Manager
More Actions


Device Manager
File Action View Help
(ISA) 0x000001A7 (423) Microsoft ACPI-Compliant System
(ISA) 0x000001A8 (424) Microsoft ACPI-Compliant System
(ISA) 0x000001A9 (425) Microsoft ACPI-Compliant System
(ISA) 0x000001AA (426) Microsoft ACPI-Compliant System
(ISA) 0x000001AB (427) Microsoft ACPI-Compliant System
(ISA) 0x000001AC (428) Microsoft ACPI-Compliant System
(ISA) 0x000001AD (429) Microsoft ACPI-Compliant System
(ISA) 0x000001AE (430) Microsoft ACPI-Compliant System
(ISA) 0x000001AF (431) Microsoft ACPI-Compliant System
(ISA) 0x000001B0 (432) Microsoft ACPI-Compliant System
(ISA) 0x000001B1 (433) Microsoft ACPI-Compliant System
(ISA) 0x000001B2 (434) Microsoft ACPI-Compliant System
(ISA) 0x000001B3 (435) Microsoft ACPI-Compliant System
(ISA) 0x000001B4 (436) Microsoft ACPI-Compliant System
(ISA) 0x000001B5 (437) Microsoft ACPI-Compliant System
(ISA) 0x000001B6 (438) Microsoft ACPI-Compliant System
(ISA) 0x000001B7 (439) Microsoft ACPI-Compliant System
(ISA) 0x000001B8 (440) Microsoft ACPI-Compliant System
(ISA) 0x000001B9 (441) Microsoft ACPI-Compliant System
(ISA) 0x000001BA (442) Microsoft ACPI-Compliant System
(ISA) 0x000001BB (443) Microsoft ACPI-Compliant System
(ISA) 0x000001BC (444) Microsoft ACPI-Compliant System
(ISA) 0x000001BD (445) Microsoft ACPI-Compliant System
(ISA) 0x000001BE (446) Microsoft ACPI-Compliant System
(ISA) 0x000001BF (447) Microsoft ACPI-Compliant System
(ISA) 0x000001C0 (448) Microsoft ACPI-Compliant System
(ISA) 0x000001C1 (449) Microsoft ACPI-Compliant System
(ISA) 0x000001C2 (450) Microsoft ACPI-Compliant System
Actions
Device Manager
More Actions


Device Manager
File Action View Help
(ISA) 0x000001C2 (450) Microsoft ACPI-Compliant System
(ISA) 0x000001C3 (451) Microsoft ACPI-Compliant System
(ISA) 0x000001C4 (452) Microsoft ACPI-Compliant System
(ISA) 0x000001C5 (453) Microsoft ACPI-Compliant System
(ISA) 0x000001C6 (454) Microsoft ACPI-Compliant System
(ISA) 0x000001C7 (455) Microsoft ACPI-Compliant System
(ISA) 0x000001C8 (456) Microsoft ACPI-Compliant System
(ISA) 0x000001C9 (457) Microsoft ACPI-Compliant System
(ISA) 0x000001CA (458) Microsoft ACPI-Compliant System
(ISA) 0x000001CB (459) Microsoft ACPI-Compliant System
(ISA) 0x000001CC (460) Microsoft ACPI-Compliant System
(ISA) 0x000001CD (461) Microsoft ACPI-Compliant System
(ISA) 0x000001CE (462) Microsoft ACPI-Compliant System
(ISA) 0x000001CF (463) Microsoft ACPI-Compliant System
(ISA) 0x000001D0 (464) Microsoft ACPI-Compliant System
(ISA) 0x000001D1 (465) Microsoft ACPI-Compliant System
(ISA) 0x000001D2 (466) Microsoft ACPI-Compliant System
(ISA) 0x000001D3 (467) Microsoft ACPI-Compliant System
(ISA) 0x000001D4 (468) Microsoft ACPI-Compliant System
(ISA) 0x000001D5 (469) Microsoft ACPI-Compliant System
(ISA) 0x000001D6 (470) Microsoft ACPI-Compliant System
(ISA) 0x000001D7 (471) Microsoft ACPI-Compliant System
(ISA) 0x000001D8 (472) Microsoft ACPI-Compliant System
(ISA) 0x000001D9 (473) Microsoft ACPI-Compliant System
(ISA) 0x000001DA (474) Microsoft ACPI-Compliant System
(ISA) 0x000001DB (475) Microsoft ACPI-Compliant System
(ISA) 0x000001DC (476) Microsoft ACPI-Compliant System
(ISA) 0x000001DD (477) Microsoft ACPI-Compliant System
Actions
Device Manager
More Actions


Device Manager
File Action View Help
(ISA) 0x000001DD (477) Microsoft ACPI-Compliant System
(ISA) 0x000001DE (478) Microsoft ACPI-Compliant System
(ISA) 0x000001DF (479) Microsoft ACPI-Compliant System
(ISA) 0x000001E0 (480) Microsoft ACPI-Compliant System
(ISA) 0x000001E1 (481) Microsoft ACPI-Compliant System
(ISA) 0x000001E2 (482) Microsoft ACPI-Compliant System
(ISA) 0x000001E3 (483) Microsoft ACPI-Compliant System
(ISA) 0x000001E4 (484) Microsoft ACPI-Compliant System
(ISA) 0x000001E5 (485) Microsoft ACPI-Compliant System
(ISA) 0x000001E6 (486) Microsoft ACPI-Compliant System
(ISA) 0x000001E7 (487) Microsoft ACPI-Compliant System
(ISA) 0x000001E8 (488) Microsoft ACPI-Compliant System
(ISA) 0x000001E9 (489) Microsoft ACPI-Compliant System
(ISA) 0x000001EA (490) Microsoft ACPI-Compliant System
(ISA) 0x000001EB (491) Microsoft ACPI-Compliant System
(ISA) 0x000001EC (492) Microsoft ACPI-Compliant System
(ISA) 0x000001ED (493) Microsoft ACPI-Compliant System
(ISA) 0x000001EE (494) Microsoft ACPI-Compliant System
(ISA) 0x000001EF (495) Microsoft ACPI-Compliant System
(ISA) 0x000001F0 (496) Microsoft ACPI-Compliant System
(ISA) 0x000001F1 (497) Microsoft ACPI-Compliant System
(ISA) 0x000001F2 (498) Microsoft ACPI-Compliant System
(ISA) 0x000001F3 (499) Microsoft ACPI-Compliant System
(ISA) 0x000001F4 (500) Microsoft ACPI-Compliant System
(ISA) 0x000001F5 (501) Microsoft ACPI-Compliant System
(ISA) 0x000001F6 (502) Microsoft ACPI-Compliant System
(ISA) 0x000001F7 (503) Microsoft ACPI-Compliant System
(ISA) 0x000001F8 (504) Microsoft ACPI-Compliant System
Actions
Device Manager
More Actions


Device Manager
File Action View Help
(ISA) 0x000001F8 (504) Microsoft ACPI-Compliant System
(ISA) 0x000001F9 (505) Microsoft ACPI-Compliant System
(ISA) 0x000001FA (506) Microsoft ACPI-Compliant System
(ISA) 0x000001FB (507) Microsoft ACPI-Compliant System
(ISA) 0x000001FC (508) Microsoft ACPI-Compliant System
(ISA) 0x000001FD (509) Microsoft ACPI-Compliant System
(ISA) 0x000001FE (510) Microsoft ACPI-Compliant System
(ISA) 0x000001FF (511) Microsoft ACPI-Compliant System
(PCI) 0x00000010 (16) High Definition Audio Controller
(PCI) 0x00000013 (19) Intel(R) Active Management Technology - SOL (COM5)
(PCI) 0x00000020 (32) Intel(R) Serial IO I2C Host Controller - 7E78
(PCI) 0xFFFFFFED (-19) Intel(R) AI Boost
(PCI) 0xFFFFFFEE (-18) Intel(R) Management Engine Interface #1
(PCI) 0xFFFFFFEF (-17) Intel(R) Graphics
(PCI) 0xFFFFFFF0 (-16) Intel(R) Ethernet Controller I226-V
(PCI) 0xFFFFFFF1 (-15) Intel(R) Ethernet Controller I226-V
(PCI) 0xFFFFFFF2 (-14) Intel(R) Ethernet Controller I226-V
(PCI) 0xFFFFFFF3 (-13) Intel(R) Ethernet Controller I226-V
(PCI) 0xFFFFFFF4 (-12) Intel(R) Ethernet Controller I226-V
(PCI) 0xFFFFFFF5 (-11) Intel(R) Ethernet Controller I226-LM
(PCI) 0xFFFFFFF6 (-10) Intel(R) Ethernet Controller I226-LM
(PCI) 0xFFFFFFF7 (-9) Intel(R) Ethernet Controller I226-LM
(PCI) 0xFFFFFFF8 (-8) Intel(R) Ethernet Controller I226-LM
(PCI) 0xFFFFFFF9 (-7) Intel(R) Ethernet Controller I226-LM
(PCI) 0xFFFFFFFA (-6) Intel(R) USB 3.20 eXtensible Host Controller - 1.20 (Microsoft)
(PCI) 0xFFFFFFFB (-5) Intel(R) USB 3.20 eXtensible Host Controller - 1.20 (Microsoft)
(PCI) 0xFFFFFFFC (-4) Standard SATA AHCI Controller
(PCI) 0xFFFFFFFD (-3) PCI Express Root Port
Actions
Device Manager
More Actions