# **Quick Installation Guide**



NO. G03-JC320QIG01-F Rev: 3.0 Release date: 2016-12-22

The photos in this file are for illustration purpose only. The model may not be the latest version. Please refer to the product you purchased for actual specification.





1. Locate the screws at the spots 2. Lift the cover up to open the chassis marked on this side of the system We use the model with pre-installed and unscrew them one by one. Wi-Fi card for installation guide.

OUICE:
311 series & 320 series are integrated with the same board and share many installation steps. Most of the illustration photos in this quick installation guide are taken from model 311 series, unless otherwise stated.

### II. To Open the Chassis of 320 Series



Locate the screws at the spots marked on this side of the system and unscrew them one by one.



2. Remove the screws in the marked 3. Remove the screws in the marked





Remove the screws in the marked 5. Lift the cover up to open the chassis. We use the model with pre-installed Wi-Fi card for installation guide.

### III. To Install SO-DIMM to the board



1. Locate the SO-DIMM slot on the



Insert the gold-figure side of the compatible SO-DIMM into the slot at a 30 degree and then press down. The eject tab will lock it if installed correctly.

# IV. To Install MSATA Card

Notice:
Please take the steps listed below before installing MSATA card over pre-installed WIFI card, for better heat dissipation: 1. Find the two thermal grease packages in the accessories pack. 2 Tear of the protective films from both side of the thermal grease package and apply the grease packages upon both sides of the L-shape metal plate. 3. Place the metal plate upon the installed WIFI card before installing the MSATA card over the WIFI card.



1. Locate the full-size MSATA slot on the board.



2. Remove the marked screw and use it to lock MSATA card to the slot in later installation.



Insert the gold-figure side of the compatible MSATA card into the slot at a 30 degree angle and press down. Insert the gold-figure side of the compatible MSATA card into the

# V. To VESA Mount the System



I. Locate the two screw holes reserved for .....VESA mount on the cover of the system.

Take note of the directions of the system.



 Place the VESA mount panel upon the cover. Tighten up compatible screws to lock the chassis to the panel as the photo shows.



3. Unlock the reserved screws for VESA mount on the back cover of the monitor



5. Check again to make sure the screws are matched and fixed stably

## VI. To Wall Mount the System



Locate the two screw holes reserved for wall mount on the cover of the system.

Take note of the directions of the system.



Adjust the chassis with wall mount panel to the wall and lock it to the wall by tightening up the above marked screws on the top side



## VII. To Install DIN Rail Mounting Clips (Optional for 311 Series)



Find the DIN rail mounting clip in the attached accessories package.
Place the clip upon VSEA mount rack, in the direction as the photo shows.
 The screw holes on the back side of the clip should match the clip should match shows.






Turn the rack over and use compatible 2.75 mm screws in the attached accessories package to lock the clip to the rack.

Install the VSEA mount rack to the barebone system by tightening up compatible screws in the above — marked spots, as the photo shows.

## VIII. To Install Hard Disk (Optional for 320 Series)



To connect SATA power connector onboard.

1. Find compatible SATA cable for the system in the attached accessories package.

2. Plug this side of the HDD cable to SATA power-in connector and SATA connector of the hard disk.



3. Turn the HDD tray over and adjust the hard disk.
... on the other side. Lock the hard disk to the HDD
tray by tightening up the screws on the marked
spots

Plug the other side of the cable to the SATA power connector and SATA port connector on the board.



5. Put the HDD tray with hard disk installed to its original place and lock the tray to the barebone system by tightening up the screws in the marked spots.

After the above installation steps completed, please put the cover to the original place and tighten up the screws previously removed (refer to part I&II).