

# Quick Installation Guide



**HBJC366R3399-2C**





**HBJC366R3399L-2C**

**NO. G03-JC366QIG02-F**  
**MB Model: JR3399XH-2C / JR3399XL-2C**  
**Rev: 2.0**  
**Release Date: 2023-03-20**



**Notice:**

The photos in this file are for illustration purpose only. The model may not be the latest version. Please refer to the product you purchased for actual specification.

**I. Mechanical Drawings**





**HBJC366R3399-2C**



**HBJC366R3399L-2C**


**\*Note:** This file servers as general installation guide with HBJC366R3399-2C product photos as installation illustration. If there are differences in specifications, please refer to the product you purchased for actual specification.

## II. To Open the Chassis



1. Locate the screws in the spots marked on the top cover of the system and unscrew them one by one.


2. Turn over the bare bone system with the heatsink upwards, as the photo shows.



3. Remove the screws in the marked spots on the front panel.




4. Remove the screws in the marked spots on the rear panel.



5. Lift the cover up to open the chassis and the front panel, the internal structural view of the system for further installation.

### III. To Install Mini-PCle Card (Full-Size)



1. Locate the full-size Mini-PCle slot on the board.
2. Remove the marked screw and use it to lock Mini-PCle card to the slot in later installation.
3. Install the adaptor bracket for half size Mini-PCle card




3-1. Locate the spots on the card.



3-2. Put the card on the bracket and secure the card to the bracket by tightening up the screw to the marked spot.

**\*Note:** In the case that compatible Full-size Mini-PCIE card is available, Step-3 for half-size card extension can be skipped.



4. Insert the golden-finger side of the compatible Mini-PCle card into the slot until golden-finger side fully plugged into the slot.
5. Lock the card to the board by tightening up the screw to the marked spot.

**Notice:** When all necessary installations are finished, please make sure that all cables unplugged before installations are connected to their original locations before restoring the cover to the chassis and screws on the cover locked to its original locations (**Refer to Part II**). See to it that the cables inside are not blocked or pressed.

## Regulatory Compliance:

### Disclaimer

This QIG is intended to be used as a practical and informative guide only and is subject to change without prior notice. It does not represent commitment from Jetway Information Co., Ltd. Jetway shall not be liable for direct, indirect, special, incidental, or consequential damages arising out of the use of the product or documentation, nor for any infringements upon the rights of third parties, which may result from such use.

## Declaration of Conformity

### FCC Statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at user's own expense.

*\*Note: 1. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. 2. Shielded interface cables must be used in order to comply with the emission limits.*

### CE Notice

The product described in this QIG complies with all applicable European Union (CE) directives if it has a CE marking. For computer systems to remain CE compliant, only CE-compliant parts may be used. Maintaining CE compliance also requires proper cable and cabling techniques.

